

Light Duty Chiller with Built-In Water Tank



The ORION 3-series chiller lineup has the right chiller to meet your diversified needs

Jun. 2023		D-RG11E
Light Duty Chiller with	Built-In	Water Tank Catalog

Choose Your ORION Built-In Water Tank Chiller!

Price Performance Position of 3 Series of Chillers

With our 3-Series Lineup, we have the best chiller to balance your needs and budget.



3-Series Lineup

Model		High-Spec Model Inverter control gives improved energy savings and high-precision temperature control.											
Ser	ries		RKE										
Air / Wate	er Cooled		Air cooled		Water	cooled							
Model *1		RKE 750A2-V-G2	RKE 1500B2-V-G2	RKE 2200B1-V-G2	RKE 1500B1-VW-G2	RKE 2200B1-VW-G2							
Control Accuracy	°C												
Power Source	V(Hz)		Thre	ee-phase 200 (50 / 60) 220	(60)								
Cooling Capacity ^{*2}	kVV (50 / 60Hz)	2.9	5.8	9.5	6	10.4							
Flow Rate	L/min (50 / 60Hz)	10 Head: 20 / 30 m	12 / 21 Head: 50 m	28 / 43 Head: 50 m	12 / 21 Head: 50 m	28 / 43 Head: 50 m							

*1 G1 spec. also available without casters. *2 For operation on air-cooled machines when the chilled water temperature is 20 °C and the ambient temperature is 25 °C, or for watercooled machines when the chilled water temperature is 20 °C and the cooling water temperature is 32 °C. Cooling capacity is at least 95% of listed figures.

Мо	del	Mid-Spec Model RKE Economy Models Compact and Precision Temperature Control							Econom Compact an	y Model Id Economy			
Ser	ries				RKS-JM		RKS-JM RKS-GM				RK	S-J	
Air / Wate	er Cooled				Air cooled	l			W	later cooled		Air co	poled
Mod	lel *1	RKS 401J -MV	RKS 402J -MV	RKS 602J -MV	RKS 752J -MV	RKS 753J -MV	RKS 1502J -MV	RKS 1503J -MV	RKS402J-MVW	RKS 750G -MVW	RKS RKS RKS RI 750G 1500G 753J 15 -MVW -MVW -V -		
Control Accuracy	°C						±0.1					±	2
Power Source	V(Hz)	Single- phase 100 (50 / 60)	S	ingle-phas 200 - 230 (50 / 60)))	Three- phase 200 (50 / 60) 220 (60)	Single- phase 200 - 230 (50 / 60)	Three- phase 200 (50 / 60) 220 (60)	Single-phase 200 - 230 (50 / 60)	ase Three-phase 30 200 (50 / 60))) 220 (60)		Three- 200 (5 220	phase 0 / 60) (60)
Cooling Capacity ^{*2}	kVV (50 / 60Hz)	1.3	/ 1.5	1.8/2.0 2.2/2.5 4.9/5.3 1.3/1.5 2.2/2.5 4.9/5.3		2.2 / 2.5	4.9 / 5.3						
Flow Rate	L/min (50 / 60Hz)	10 Head: 30 m			1 Head:	8 : 60 m	10 Head: 30 m	10 Head: 20 / 30 m	12 / 21 Head: 50 m	10 Head: 20 / 30 m	12 / 21 Head: 50 m		

*2 For operation on air-cooled machines when the chilled water temperature is 20 °C and the ambient temperature is 25 °C, or for water-cooled machines when the chilled water temperature is 20 °C and the cooling water temperature is 32 °C. Cooling capacity is at least 95% of listed figures.

Making the Right Model Choice

Sample cooler heat calculation and model selection methods are listed below. Please make a model choice that best suits your operating conditions and requirements.

Example 1 Find the cooling capacity required to deal with heat generated by a piece of equipment which is to be cooled by a chilled water flow ; the temperature difference between the cooling water going into and out of the equipment is known.

The equipment to be cooled is accepting a cooling water flow of 12 L/min, the water temperature going into the equipment is 17 $^{\circ}$ C, and the temperature of the water coming out is 20 $^{\circ}$ C. What is the amount of heat being generated by this equipment?

$$Q = \frac{(t2-t1) \times X \times C \times \rho}{60} = \frac{(20-17) \times 12 \times 4.2 \times 1}{60} \approx 2.5 \text{kJ/s} = 2.5 \text{kW}$$

Note: When making a model selection, also consider heat from external sources that might raise the water temperature. In order to compensate for such external heat sources, it is recommended that an additional 20% in cooling capacity be added to the calculation. $Q = 2.5 \times 1.2 = 3.0 \text{kW}$

Example 2 In case a certain temperature drop is required in a fixed amount of time.

For example, if 40 L of 20 $^\circ\text{C}$ water is in a separate tank, what is the heat dissipation required to lower the temperature of the water to 5 $^\circ\text{C}$ in one hour?

$$Q = \frac{W \times C \times (t2-t1)}{H} = \frac{40 \times 4.2 \times (20-5)}{3600} = 0.7 \text{ kJ/s} = 0.7 \text{ kW}$$

Note: When making a model selection, also consider heat from external sources that might raise the water temperature. In order to compensate for such external heat sources, it is recommended that an additional 20% in cooling capacity be added to the calculation. $Q = 0.7 \times 1.2 = 0.84 \text{kW}$

Q: Amount of heat in kW (kW = kJ/s)	C: Specific heat
W: Weight of liquid to be cooled	(kJ/kg°C, 4.2 in case of water)
(volume (L) x specific gravity)	t2: Upper temperature (°C)
p: Specific gravity	t1: Lower temperature (°C)
(kg/L, 1 in case of water)	H: Required cooling time in second
	X: Water flow per minute (L/min)

Application Examples by Series

High Energy Savings and Precision Control (±0.1 °C)

Fiber Laser

supply cooling.

Diode laser oscillator and optical systems cooling.



High Frequency Induction Heating

Heating coil cooling and high frequency power

MRI

Helium compressor cooling and gradient coil cooling.



Plasma Welder

torch.

Cooling for power supply and welding

Photolithography Equipment

 $\pm 0.1^\circ\text{C}$ cool water supply for exposure stage (cool plate).



ICP Analysis Equipment Improved cooling efficiency for inspection solutions.



RKE Series Economy Models Offer Low Price in a Compact Design AND High Precision Temp. Control (±0.1 °C)

RKS-JM Series

*If a water cooled model is needed, then please order from the RKS-GM Series.

Concentrating Equipment



YAG Welding Machine Laser Oscillator Cooling.



Analysis Equipment

Analysis stage cooling.



UV Laser Engraving Machine Laser Light-source Cooling.



Printing Equipment UV lamp cooling and ink drying cooling stage cooling as well as control over ink temperature.



X-Ray Inspection Equipment

X-Ray Tube Cooling.



Molding Machines Mold and hopper cooling.



Sheet Printing Machine Individual roller cooling.





Three - phase 200 (50/60)

Power Source

V (Hz)

4

High Energy Savings and Precision Control (±0.1 °C)

RKE Series



Fully Loaded with Superior Functionality to Meet All the Requirements of Your Application and Working Environment.

High-Spec Model

Cooling Capacity(50/60 Hz):	2.7kW – 8.7 kW(Air Cooled) 6.0kW – 10.4 kW(Water Cooled)
Ambient Temp. Range:	-5 - 43 °C(Air Cooled) 2 - 43 °C(Water Cooled)
Operable Temp. Range (Liquid temp.) :	5 – 35 °C
Temp. Control Precision:	±0.1 °C

Minimum 30 % Energy Savings* AND Precise

Temperature Control of 0.1 °C ! • Compared with our earlier models.



Energy Saving

As much as 65% Energy Savings Possible

Even compared with power saving ON/OFF type chillers, our DC Inverter control models offer energy savings of 30 % at full load.

And when compared with temperature-stable hot gas bypass or PID proportional valve controlled chillers, a 65 % reduction in energy requirements is possible.



No Trade-Off between Low Energy and High Accuracy Control -- Now Orion Offers Both!

Our inverter controlled compressor responds to fluctuating workloads linearly, achieving highly accurate temperature control while using the least amount of energy.

Plus, thanks to Orion's distinctive capacitycontrol system, accurate temperature control can still be maintained during normally difficult to control low load situations.

(User can choose between "High-accuracy" and "Energy saving" modes in response to low-load conditions.)



High Accuracy Temperature Control

Temperature Control Accuracy to ±0.1 °C*

Precise control even for applications that have severe temperature management requirements. Its extreme versatility makes it suitable for a wide range of applications, including precision-production-use lasers, analysis devices, semiconductor manufacturing, and many others.



Wide Range of Operating Conditions

Liquid Temp. Control Range: 5 – 35 °C allows for wide-ranging applications. High temp. operation possible for piping condensation prevention, etc. Works in an increased range of ambient temperatures* from -5 to +43 °C. (Water cooled types from +2 °C.) This means our chiller can do its job under even harsher working conditions.

* For ambient temperatures below 5 °C, measures must be taken to ensure that piping outside the chiller does not freeze.



Built for Improved Ease of Use



Slanted front panel design is easy to see and easy to operate.



Tank access is at the top for easy access, easy water quality confirmation, easy cleaning!



Easy "One Touch" removable condenser dust filter. (Air cooled model only)

Wealth of Accessories (Sold Separately) and Multi-Function Parameters

Operation and control functions, as well as water temperature control conditions monitoring all from your PC via a single cable hookup.



Equipped with a Wealth of Accessories (Sold Separately). Users have many options to choose from such as Remote control. Heaters. Communica-

tion software, and others to further suit their application requirements and operating environment. CE certification on built-to-order models is available.

Using the Multi-Function Parameters, users can tailor the chiller operation to best suit their many needs and operating conditions.

Function	Description
Power Outage Recovery Setting	"No recovery", "Auto recovery", "Remote switch priority", and "Either Local or Remote Switch On" options available.
ocal or Remote Operation	Choose from: "Local Only", "Remote Only", "Both Local/Remote".
Narm Signal Output	Can select signal contacts to be "Open" or "Closed" during an alarm condition.
Alarm State Operation Control	Options to "Continue" or "Halt" operation of still-working components under warning conditions.
Audible Alarm	Audible alarm "Enabled" or "Disabled" during alarm condition.
Audible Warning	Audible alarm "Enabled" or "Disabled" during warning condition.
reeze Prevention Operation	To prevent freezing, auto pump operation "Enabled" and "Disabled" options available.
Varm-Up Mode	Option to keep pump running even when chiller is off, in order to maintain a (set) minimum liquid temperature.
Energy Saving Mode	Option to shut off compressor when cooling load falls below 40 % for increased energy savings.
.ow-Noise Mode	Option to reduce noise output by lowering the maximum fan speed to 40 Hz or lower. (Cooling power reduced about 20 %.)
i00-Hour Filter Timer	Warning alarm to replace the filter after 500 hours can be enabled or disabled.
iquid Temp High/Low Warning	5 patterns of water temperature limit settings are, available.

Example of Energy Saving Configuration

RKS1500F-V Changing to the RKE1500B2-V 44 % Energy Saving

Reduced Output of CO₂ -1,111 kg-CO₂/Year

61,750 JPY/Year

Effective Savings

Comparison Conditions

Compared Models	RKS1500F-V (ON/OFF Control)
	RKE1500B2-V (DC Inverter Chiller)
Set Water Temp.	20 °C
Average Load	3.2 kW
Operating Time	10 Hours/Day (250 Days/Year)
Electricity Cost	25 JPY/kWh

Amount of CO₂ Emission Reduction

* CO2 emission coefficient used is 0.450, the average of 9 power companies.



Energy Savings Points

Got a Big Heat Load? Change to an Inverter Chiller!

Power Consumption Rate Based On Chiller Load Factor



Yearly Power Consumption Comparison



RKE Series

Specifications Chart

						Air Cooled					
		Model			RKE750A2-V-G1 RKE750A2-V-G2 (w/ casters)	RKE1500B2-V-G1 RKE1500B2-V-G2 (w/ casters)	RKE2200B1-V-G1 RKE2200B1-V-G2 (w/ casters)				
Per	Cooling	Room Temp. 32 °C,	Set Temp. 20 °C*1	kW	2.7	5.3	8.7				
form	Capacity	Room Temp. 25 °C,	Set Temp. 20 °C	kW	2.9	5.8	9.5				
ano	Ambient Temp.	Range		°C		-5 - 43					
dS e	Operating Temp	o. Range (Liquid	Temp.)	°C		5 – 35					
ecifi	Control Precis	sion*4		°C	±0.1 (Un	±0.1 (Under stable load, ambient temperature and power source.)					
catic	CONTROLFTECK	51011		C	±0.5 (When the current load is continuously within ±10%.)						
suc	Min. Operating C	irculation Rate (50	/60 Hz)	L/min	10 (Head: 20 / 30 m)	12 / 21 (Head: 50 m)	28 / 43 (Head: 50 m)				
Pov	Power Source	9 ^{*2}		V(Hz)		Three-phase 200±10 % (50 / 60), 220±10 % (60)					
ver	Power Consu	mption (50/60 H	Z) *1	kW	1.2 / 1.3, 1.3	2.3 / 2.4, 2.4	4.6 / 4.7, 4.7				
Spe	Electric Curre	ent (50/60 Hz) *1		A	4.5 / 5.3, 4.7	8.7 / 9.0, 9.0	16 / 17, 17				
cific	Power Capac	ity*3		kVA	2.1	4.2	6.5				
ations	Breaker Capa	Breaker Capacity		А	10 (With heater installed: 15) Current sensitivity: 30 mA, High-speed	15 (With heater installed: 20) Current sensitivity: 30 mA, High-speed	30 ^{°6} Current sensitivity: 30 mA, High-speed				
Op	eration Control	Method			L	Compressor Speed Control					
	Comprossor	0		n	Fully sealed rotary type (Inverter driven)						
	Compressor		Output	kW	0.7 1.7						
	Condenser				Fin and tube heat exchanger						
qui	Heat exchance	1er	Construction	n	Plate type heat exchanger						
pme			Material			SUS316 (Brazing: Cu)					
nt	Discharge Pu	mn	Construction	n		Cascade type					
)etai	Discharge i u	ΠP	Output	kW	0.25	0.40	0.75				
S	Water Tank C	apacity		L	appro	ox. 15	approx. 20				
	Refrigerant					R410A					
Cha	arged Amount			kg	0.75	1.10	1.40				
CE	Marking				-	-7	Built To Order				
Ext	ernal Dimensio	ns (H × D ×W)		mm	G1: 840 × 688 × 400 G2: 927 × 688 × 400	G1: 879 × 850 × 400 G2: 966 × 850 × 400	G1: 993 × 970 × 530 G2: 1080 × 970 × 530				
Pro	duct Mass (Dry	weight)		kg	G1: 68 G2: 73	G1: 96 G2: 100	G1: 135 G2: 140				
Op	perating Noise Level (50/60Hz) ^{-s} dB 55 / 57 56 / 60 62 / 64				62 / 64						

					Water 0	Cooled					
		Model			RKE1500B1-VW-G1 RKE1500B1-VW-G2 (w/ casters)	RKE2200B1-VW-G1 RKE2200B1-VW-G2 (w/ casters)					
Pe	Cooling	Room Temp. 32 °C, S	Set Temp. 20 °C*1	kW	6.0	10.4					
rform	Capacity	acity Room Temp. 25 °C, Set Temp. 20 °C kW		kW	(Chilled water temp.: 20 °C)	(Chilled water temp.: 20 °C)					
lano	Ambient Temp. Range °C		°C	2 - 43							
e Spec	Operating Temp	. Range (Liquid T	emp.)	°C	5 –	35					
ecifi	Control Precis	tion*4		°C	±0.1 (Under stable load, ambient	temperature and power source.)					
catic				Ŭ	±0.5 (When the current load is	s continuously within ±10 %.)					
suc	Min. Operating Ci	rculation Rate (50/6	60 Hz)	L/min	12 / 21 (Head: 50 m)	28 / 43 (Head: 50 m)					
Pow	Power Source	*2		V(Hz)	Three-phase 200±10 % ((50 / 60), 220±10 % (60)					
er s	Power Consu	mption (50/60 Hz))*1	kW	1.7 / 1.8, 1.8	3.5 / 3.7, 3.7					
pec	Electric Curre	nt (50/60 Hz) *1		Α	6.5 / 7.1, 6.6	14 / 14, 14					
ifica	Power Capaci	ity*3		kVA	3.0	5.5					
tions	Breaker Capa	city		А	15 (With heater installed: 20) Current sensitivity: 30 mA, High-speed	30 ^{°6} Current sensitivity: 30 mA, High-speed					
Ope	eration Control N	Vethod			Compressor S	Compressor Speed Control					
	0		Construction		Fully sealed rotary type (Inverter driven)						
	Compressor		Output kW		0.7 1.7						
Ē	Condenser				Double pipe water cooling						
uipn	Heat exchang	er –	Construction	n	Plate type heat exchanger						
nent	Theat excitaing	01	Material		SUS316 (Brazing: Cu)						
Det	Discharge Pu	mn –	Construction	n	Cascad	ie type					
ails	Discharge i u	inp –	Output	kW	0.4	0.75					
	Water Tank Ca	apacity		L	approx. 15	approx. 20					
	Refrigerant				R41	10A					
Cha	rged Amount			kg	0.80	1.10					
CE	Marking				Built To	Order					
Exte	ernal Dimension	ns (H × D ×W)		mm	G1: 879 × 850 × 400 G2: 966 × 850 × 400	G1: 993 × 970 × 530 G2: 1080 × 970 × 530					
Pro	duct Mass (Dry	weight)		kg	G1: 95 G2: 98	G1: 135 G2: 140					
Ope	erating Noise Le	evel (50/60Hz)*5	5	dB	55	59 / 60					

¹ For operation on air-cooled machines when the chilled water temperature is 20 °C and the ambient temperature is 32 °C, or for water-cooled machines when the chilled water temperature is 32 °C. Cooling capacity is at least 95% of listed figures. ¹ Source voltage phase unbalance should be less than 43 %. ¹ The figure noted is when operating at the highest capacity in the normal operating range. ¹ Does not include starting times or when the cooling load is too small, in which case the compressor may cycle on and off. ¹5 Operating noise levels are from a position of 1 m in front of the product and at a height of 1 m. ⁶ Unit comes with a built-in overload protection breaker. ¹ 7 CE Marking is available on the older RKE750A1-V and RKE1500B1-V models. (Built to order). Note 1: Liquid (chilled water) that can be used are either clean water and a 30 to 40% ethylene glycol solution. Alternatively, if deionized water is to be used, it should have an electrical conductivity of at least 1. Sicm. Note 2: Do not use aluminum parts for parts that will be wetted with the chilled water. Electrolytic corrosion of aluminum can cause clogging in the heat exchanger. Note 3: Heat output from the unit (in kW) is approx. 1.3 times that of the cooling capacity.

Cooling Capacity



Minimum Heat Requirement for Inverter Control <Conditions> Chilled Liquid: Water

* Even in the high accuracy mode, if the amount of heat to process is below the minimum level, the compressor will cycle ON and OFF, and may affect the control accuracy.
* If the minimum heat requirement for inverter control is not met and high accuracy temperature control is necessary, please install the optional heater assembly unit, or ask for a special model equipped with a capacity control valve.





RKE2200B1-V RKE2200B1-VW



Discharge Pump Characteristic Curves Pump-only operation rating.

60

50

40

30

20

10

0

50 Hź

Refrigeration

777777777777

10

20

Cooler Head Loss



RKE1500B2-V / RKE1500B1-VW

60 Hz

30 40

Circulating Load (L/min)

Min. Working Circulation Rate

Min Available Working Head

50 60









8

RKE Series

External Dimensions (Units: mm)



RKE1500B2-V-G1 • G2 (Incl. casters) Anchoring Hardware G1: 4 Locations, G2: 4 Locations (For transport. Remove before operation.) Water Tank Cover <u>Φ12</u> 80 456 ¢ Ø Ventilation Direction Panel Operation Panel 420 4 M8 nuts (For Accessory (Sold Separately) eye bolt installation.) 156 540 Handle to Open and Close the Water Tan 560 4 M8 nuts 400 (For Accessory (Sold Separately) water filter installation) ۲ 400 850





RKE1500B1-VW-G1• G2 (Incl. casters) Anchoring Hardware G1: 4 Locations, G2: 4 Locations (For transport. Remove before operation.) Water Tank Cover Φ12 470.6 445.6 Handle to Open and Close the Water Tank Ì 4 M8 nuts (For Accessory (Sold Separately) eye bolt installation.) Operation Panel 540 156 ₿ ÷ Water Supply Port Access Hole (Rc 1/2 for Accessory (Sold Separately) ball tap) 4 M8 nuts (For Accessory (Sold Separately) water filter installation) Ø ·Φ Liquid Level Gauge 400 850 Water Tank Drain Valve ¢ 560 ۲ Refrigerant High-Pressure Gauge 440 ۲ 400 Overflow Water Tank Drain Rp 1/2 332 ÷ 265 165 125 Cooling Water Outlet Rc 3/4 ÷ Water Pressure Gauge 879 996 53 Cooling Water Inlet Rc 3/4 54 Freeze-Prevention Valve 120 Cooling Water Drain Rp 1/4 250 (w/ plug) 43 Wiring Access Hole (Ф38) (For remote and communication Chilled Water Inlet / Rc 1 Drain Pan Drain R1/4 Detail of Chilled Water Circuit Parts Wiring Access Hole(Ф38) (Accessory (Sold Separately) For heater.) te and communications functions Bypass Valve Chilled Water Outlet / Rc 1 Power Cord Access Hole Includes Power Cord (Length outside the product: 3 m) 2 mm² x 4-conductors





*1: Signal lines and power cords should be routed through different access holes.

*2: Casters are only included with the G2 models.

*3: When using the water supply port, the Accessory (Sold Separately) ball tap assembly should be installed.*4: Either prepare a container to collect the water from the drain pan drain or lead the drain water away

to a drainage collection site using a hose or other means. *5: Piping connection dimensions in the illustration have a maximum tolerance of ±2 mm.

High Energy Savings and Precision Control (±0.1 °C)

Equipment List

		Function			Mod	lel (RKE Sei	ries)	
	lt	em Detail	Comments	750A2-V	1500B2-V	2200B1-V	1500B1-VW	2200B1-VW
	30 to 40% solution of industrial-u	use ethylene glycol. *3			St	andard Equipme	ent	
	Deionized water Electrical Conduc	stivity: 1 uS/cm or Higher	Wetted parts are copper-free *4					
			Wetted parts are copper-free. 4				t	
	Working Liquid (Chilled water)	5-35 C			51	andard Equipme	:rit	
	Temp.		Use a 40 % ethylene glycol solution. "3			*		
0	Freeze-Prevention Mode	This function operates the discharge pump in order to prevent water temperature drops and freezing during winter months when unit operations is stopped. When enabled, the discharge pump will operate when the water temperature falls to 3 °C or below.	Control panel can be enabled or disabled. *Cannot be used at the same time as the warming up mode.		Standard Equipment			
perating Enviro	Warm Up Mode	This function will automatically operate the discharge pump at times when the product is otherwise not operating when the ambient temperature is low, for example during winter months, in order to prevent the water temperature from dropping too much and in order to help maintain the set water temperature. When the mode is enabled, the water temperature can be set between 10 °C and 35 °C.	Control panel can be enabled or disabled, *Cannot be used at the same time as the freeze- prevention mode.		Standard Equipment			
Imen	Low Noise Mode	This function will limit the upper speed of the fan and the fan ventilation noise level will be decreased.	Can be enabled or disabled via the control panel.		St	ent		
Ŧ	Leakage Alarm Spec.	In addition to the standard specification, leak-detect spec. models include leak-detection functionality (leakage sensor and leakage detection unit) built in. Pressure resistant piping, insulated refrigeration, piping, insulated water piping standard. (For models specified with leak detection specifications.)			*			
	Water Leakage Detection	In addition to the standard specification, leak-detect spec. models include leak-detection functionality (leakage sensor and leakage detection unit) built in.				*		
	Vibration Reducing Base	Reduces transmission of vibration from the chiller.		0A003698000	0A002692000	0A003448000	0A002692000	0A003448000
	Discharge Pump Specs. *1	High-head pump Please consult us on each occasion.				*		
	Relief Valve (Pressure valve)	Can provide equipment-side pressure protection.	Pressure valve: Set to 0.3 - 0.5 MPa. (If a pressure greater than 0.5 MPa is desired, please consult your dealer regarding pressure-resistance of the product and the installed pump. Our dealers are glad to assist you at any time.)			*		
	Water Tank Water-Level Alarm (Lower limit alarm)	Used to avoid water shortages due to evaporation.			St	andard Equipme	ent	
	Automatic Water Supply	A ball tap is provided in the water tank in order to maintain a uniform water level.	The special ball tap is installed on-site. *2	03101256010	03101256010	03103698010	03101256010	03103698010
		Shipped with ball tap pre-installed.		*				
		Gate valves are added to the chilled water inlet and outlet ports.	Gate Valve: Same port diameter as the product inlet and outlet ports. (Material: Choose between SUS or brase.)	Brass 04106229010 SUS		041062	229030	
	Chilled Water Inlet/Outlet Open/Close		01255.)	04106229020		041062	229040	
		Solenoid valve are added to the chilled water inlet	Solenoid Valve: Same port diameter as the product inlet and					
5		and outlet ports.	outlet ports (Material: brass).	×				
illed		Compression fittings are added to the chilled water inlet and outlet ports.	Hose Coupling: Port diameter matched to the product inlet and outlet ports.	04106230010		041062	230020	
Wa		Water Filter A Assembly	Choose the filtration level. (5 µm)	03108547010				
ter		Water Filter A Assembly	Choose the filtration level. (10 µm)			03108547020		
<u>Ω</u>	Chilled Water Circuit Water	Water Filter A Assembly	Choose the filtration level. (20 µm)			03108547030		
rcu	Filler	Water Filter A Assembly	Choose the filtration level. (50 µm)	03108547040				
Ŧ		Water Filter A Assembly	Choose the filtration level. (100 µm)			04100489010		
		Deionizer "F" Assembly		04101	157010		04101157010	
	Deionized Water Equipment for	Deionizer "H" Assembly	Water sample quality of 10 µS/cm or lower	001			01101101010	
	Chilled Water Circulation Circuit	Deionizer "G" Assembly			_	04103028010	_	04103028010
	Deionized Water Equipment for	Deionizer assembly for supply water				04100522010		04100020010
		Gate valves are added to the cooling water inlet and	Gate Valve: Same port diameter as the product inlet				041062310)10 (Brass)
	Cooling Water (Condenser circuit) Inlet/Outlet Open/Close	outlet ports.	and outlet ports. (Material: Choose between SUS or brass.)		_		04106231	020 (SUS)
	*Model names ending with "W" are targeted for water cooled chillers.	Cooling water inlet and outlet ports have solenoid valves added.	Solenoid Valve: Same port diameter as the product inlet and outlet ports (Material: brass).		_		,	k
		Compression fittings are added to the cooling water inlet and outlet ports.	Compression Fitting: Port diameter matched to the product inlet and outlet ports.		_		041062	230030
	Bypass Circuit	The bypass circuit is operated by manually opening and closing the cooling water circuit valves.	RKE models have the bypass circuit built-in. The circuit is external on RKS models.		Standa	rd Equipment (B	uilt-in)	
		Three-phase 200 V (50/60 Hz), Three-phase 220 V (60 Hz)			St	andard Equipme	ent	
Pov	Primary Power Supply Voltage	Three-phase 230 V (50 Hz), 380 V • 400 V • 415 V • 440 V • 480 V (50/60 Hz)	The autotransformer is installed externally.			*		
ver Sup	Overload Safety Devices	Built-in overload safety device.	RKE2200 models come standard with an earth leakage breaker (current sensitivity; 30 mA) and RKS series models come standard with a no-fuse breaker. "RKE7501500 models and RKS models have a leakage breaker available as a manufacturer option.	7	ł	Standard Equipment	*	Standard Equipment
oply and	Power Outage Recovery Operation Settings	Selects recovery pattern after power outage. (Manual recovery • Automatic recovery • Remote operation priority)	Action to be taken after recovery can be enabled or disabled via the control panel.		St	andard Equipme	ent	
dС	Operation Action Settings	tion Settings Can choose between "Local" and "Remote" operation. Can be set from the control panel.			St	andard Equipme	ent	
ont	Alarm Signal Output Options	Can choose the contact state of the remote alarm signal output.	Can be set from the control panel.		St	andard Equipme	ent	
rol	Audible Alarm Enable/Disable	The audible alarm/warning can be enabled or disabled	The audible alarm can be enabled or disabled via the control papel		C+	andard Equipme	ent	
Specs.	Liquid (Chilled Water) Temp. Upper/Lower Limit Warning Option	The estimate during wait we find the statute of utiliable of The method of abnormal liquid (chiled water) temperature detection can be selected. Can enable or disable the alarm and standby sequence for reality waite and absolute value alarms. Regarding the standby sequence, the alarm will be output after startup until the liquid temperature has initially	Can be set from the control panel.		Standard Equipment			
		reacheu a normal value and then later goes outside the normal range.						

= Accessory (Sold Separately) / Part Number

★ = Special Specification

		Function		Мо	del (RKE Series)		
	lt	em Detail	Comments	750A2-V 1500B2-V	2200B1-V 1500B1-VW	2200B1-VW	
	Liquid (Chilled Water) Temp. Upper/Lower Limit Warning / Absolute Value Upper Limit	The warning will occur if the water temperature goes above the set temperature (2 - 40 'C) regardless of the actual set water temperature. Will be active when the "Liquid (Chilled Water) Temperature Upper/ Lower Limit Warning" Absolute Value has been selected.	Water temperature setting can be set from the control panel.	S	Standard Equipment		
	Liquid (Chilled Water) Temp. Upper/ Lower Limit Warning / Absolute Value Lower Limit	The warning will occur if the water temperature goes below this set temperature regardless of the actual set water temperature.	Water temperature setting can be set from the control panel.	S	Standard Equipment		
		Duran a strand a second at the second of the second of	Remote Control Set C		04110397010		
	Pomoto Control	can be run and other operations can be conducted (limited	Max. wiring length: 20 m		04100541010		
	Remote Control	control) from a control panel in a location away from the	Max. wiring length: 50 m		04100541020		
			Max. wiring length: 100 m		04100541030		
N N	Communications Functions	Communications Interface and Software	Available for free download at the website.	Communica	tions Interface: 04101126010		
er Supp	Communications Device Address	Enables communications functions and selects the address number of the unit when multiple units are connected together.		5	Standard Equipment		
ly and	Settings Lock	Changes to the water temperature setting and other parameter settings can be locked out.	Can enable or disable setting changes from the control panel.	S	Standard Equipment		
d Cont	Temperature Warning Signal Output Option	Determines the open/closed state of contacts when a temperature warning signal is present.	The type of relay output (ON/OFF) when an alarm condition occurs can be selected from the control panel.	5	Standard Equipment		
0		Operation Signal Terminal Block	No-voltage contacts	5	Standard Equipment		
Spe			Voltage output (200 V output)		*		
ĊS.		Alarm Signal Terminal Block	No-voltage contacts	5	Standard Equipment		
			Voltage output (200 V output)		*		
		Remote Operation (No-voltage contacts)	Max. wiring length: 20 m	Standard Equipment			
	External Signal Operation		Max. wiring length: 100 m	*			
		Denote October (04) (de October)	Max. wiring length: 20 m(Circuit board takes 24 Vdc input power.)	*			
		Remote Operation (24 Vdc Output)	Max. wiring length: 100 m (Circuit board inputs are activated via a 24 Vdc input actuated relay on the circuit board.)	*			
		Remote Operation (200 Vac Output)	Max. wiring length: 20 - 100 m (Circuit board inputs are activated via a 200 Vac input actuated relay on the circuit board.)	*			
	CE Marking	CE Compliant Model			★ *6		
			2 locking freewheeling casters and 2 non-locking freewheeling casters.	*			
	Casters	With lock	2 free-wheeling casters, 2 fixed casters	*			
			4 free-wheeling casters	Standard Equipment(G2)			
		Powder Coating: 30 µm		5	Standard Equipment		
	External Surface Coating Thickness	Salt Corrosion Prevention Spec. (Powder coating of at least 45 $\mu m.)$	Use external screws are made of stainless steel. Condenser and refrigerant piping coated with a corrosion resistant coating.		*		
	Color Designation	Melamine resin coating of at least 15 µm.			*		
	*Specify the color designation as a JPMA No.	For other paint / coatings:			*		
	or munseil no (including a color sample).				Any Time		
0	Packaging for Export	Basic plywood packaging	Please consult your dealer for details regarding JIS standard packaging.		*		
ther	Water Temperature Control Accuracy	±0.1 °C		S	Standard Equipment		
	Heating Functionality	Used to raise the temperature during product startup. (Built in 200 Vac electric heater.) *ON/OFF control to the set Liquid temperature minus 2 °C \pm 0.5 °C.	Heating output: Selectable among 2 kW, 3 kW, 4 kW, or 5 kW.	★ (Will cl	nange external dimensions.)		
	Low-Load Response	When high-precision control is required at loads below the minimum required amount.	Optional Heater Control *5	03101359010(1.5 kW)	03104635010 03101359010 (1.8 kW) (1.5 kW)	03104635010 (1.8 kW)	
		lananese		×	X	_	
	Test Results Chart	Laparicse					
		Iananese					
	Test Results Chart	English			*		
	Initial Inspection				<u> </u>		

* 1: Cooling capacity will be reduced by an amount just equal to the amount of pump heat dissipation.

* 2: Cannot be connected directly to city tap water. Supply water using a back-flow device for the water supply tank or cistern, etc.

* 3: Max. decrease in cooling capacity is 10 %.

* 4: Copper alloy is used for wetted parts on standard units.

* 5: We can also provide an Accessory (Sold Separately) heater that will operate when starting operation.

* 6: CE Marking is available on the older RKE750A1-V and RKE1500B1-V models.

<Please Note>

Specifications for Accessory (Sold Separately) factory equipment may change without notice. Thank you for your understanding.

Mid-Grade Model RKS-JN Series

New Model Compact Chiller No. 1 Performer in a Compact Body

Loaded with Application Functionality that Confor

Mid-Grade Model



Uses Chilled Water, Suitable for a Wide Variety of Applications

Perfect for environments where heat is the enemy!

Heat Removal and Water Temperature Control for Semiconductor Research and Manufacturing Equipment, Rechargeable Cell Research and Manufacturing Equipment, Precision Measurement Equipment and Precision Processing Machines, Analysis Equipment, Medical Equipment, etc. Water Cooled *Chilled water is not CE or

UL certified.

RKS402J-MVW



Condensed Functionality! Even Easier to Use!

ms to Your Operating Environment!

Comes Standard with High Pressure Pump (Same capacity for 50/60 Hz regions)

The high pressure pump that comes standard with RKS-JM Series models is an inverter driven pump that maintains its compact size while ensuring a 10 L/min flow rate at a water pressure of 0.3 MPa. The same flow capacity is achieved even in regions with different power frequencies, so operation stability can be assured even if moved to different factory facilities.

Made Even Easier to Use! Simple and Reassuring Design

Common on All RKS J(M) Series Models

Simple and Reliably Designed **Controller + Substantial Functionality**

Easy operation with just the flick of a switch! Alarm details via error code display for quick recovery.



Output Signals

- Operation Signal
- •Alarm Signal
- Remote Signal
- Freeze-Prevention Mode

Operation Signal

- Warm Up Mode
- Discharge Pump-Only-Operation Automatic Recovery After Power Outage, etc.

Easy Filter Cleaning

Comes standard with a filter to help prevent clogging! Easy tool-less removable filter design. Filter can be directly cleaned for easy removal of dirt and reduced manpower, adding to chiller operating stability.



Large Capacity Tank with Wide Water **Supply Port**

Φ100 mm large water supply port for easy cleaning! The high capacity tank means less frequent water shortage warnings, less frequent water supplying, and less change in water temperature due to changing loads. A built-in blue LED lit water indicator for easy confirmation of water level!





Wide mouth water supply port for easy tank cleaning.

Easy to check LED lit water level daude.



Mid-Grade Model S-JM Series

Specifications Chart: Standard Models

		Madal		RKS-JM Series							
model				401J-MV	402J-MV	602J-MV	752J-MV	753J-MV	1502J-MV	1503J-MV	402J-MVW
Pe	Cooling Capacity (oling Capacity (50/60 Hz) *1 kW		1.3 / 1.5 1.8 / 2.0 2.2 / 2.5			/ 2.5	4.9 /	5.3	1.3 / 1.5	
iforn	Heating Capacity (Heating Capacity (50/60 Hz) *1 kW			0.53 / 0.53 0.6 / 0.6 1.1 / 1.1 0.38 / 0.						
nanc	Ambient Temp. Rai	Ambient Temp. Range °C					5 -	45			
e Sp	Operating Temp. Ran	ge (Liquid Temp.)	°C				5 -	- 40			
ecifi	Operating Water Pressure MPa		MPa			0.05 - 0.3			0.1 -	- 0.6	0.05 - 0.3
catic	Control Precision	*4	°C				±C).1			
SUI	Min. Operating Circulatio	n Rate (50/60 Hz)	L/min			10 (Head: 30 m)			18 (Hea	d: 60 m)	10 (Head: 30 m)
Power S	Power Source	*2	V(Hz)	Single-phase 100 ±10% (50/60)	Sing	le-phase200 – 230 ± (50/60)	10%	Three-phase 200 (50/60) • 220 (60) ±10%	Single-phase 200 – 230(50/60) -5%, +10%	Three-phase 200 (50/60) • 220 (60) ±10%	Single-phase 200 – 230(50/60) ±10%
Spec	Power Consumption ((50/60 Hz) *1	kW	0.8 / 0.7	0.9 / 1.0	1.0 / 1.1	1.1 / 1.2	0.9 / 1.0, 1.0	2.0 / 2.5	1.8 / 2.2, 2.2	0.6 / 0.6
ifica	Electric Current (50	0/60 Hz) *1	A	7.9 / 7.3	3.8 / 4.7	4.9 / 5.2	5.2 / 5.4	3.6 / 3.4, 3.4	9.5 / 11.3	6.6 / 8.2, 8.2	3.2 / 3.0
tions	Power Capacity	*3	kVA	1.2	1.5	2.0			4.	2	1.3
	Breaker Capacity	*5	A	15	10	15 10		10	30	15	10
Ope	eration Control Metho	bd				Ele	ctronic expansion	valve capacity cor	ntrol		
	Compressor						Hermetically se	aled rotary type			
	Compressor		NVV	0.55	0.6	0.75 0.85		1.2	1.8	0.6	
Equ	Condenser			Corrugated fin and tube parallel flow type Plate type heat exchanger							
lipm	Evaporator	Construction		Plate type heat exchanger							
ent		Material		SUS316 (Brazing: Cu)							
Deta	Discharge Pump	Construction					Casca	de type			
siir	Discharge Fump	Output	kW			0.25 (Inverter driven)			0.4 (Invert	ter driven)	0.25 (Inverter driven)
	Water Tank Capaci	ity	L				Appr	ox.17			
Refrigerant							R4	10A			
Charged Amount kg			kg	0.	36		0.37		0.65	0.59	0.45
External Dimensions (H × D × W) mm		mm			615 × 500 × 375			933 × 59	90 × 375	615 × 500 × 375	
Pro	duct Mass (Dry weig	ht)	kg	4	2	4	5	46	72	68	44
Exp	ort Standard CE and	d UL (60 Hz only)		_	0	0	0		0	_	
Ope	erating Noise Level	*6	dB	59 / 62	59 / 60	61	62	62 / 63	64 / 65 65 / 66 54 / 55		

¹⁴ For air-cooled models, chilled water temp.: 20 °C, ambient temp.: 25 °C. For water-cooled models, chilled water temp.: 20 °C, cooling water temp.: 25 °C, and discharge pump working at maximum load. ¹² Source voltage phase unbalance should be less than ±3 %. ¹³ The figure noted is when the equipment is operating at the highest capacity of its normal operating range. ¹⁴ When the extremel can current load is continuously within ±10 %, and the ambient temperature is stable. However does not include starting times or when the heal-load exceeds the chiller capacity. ¹⁵ Comes standard with a built neverload protection circuit breaker (NFB). ¹⁵ Operating noise levels are from a position of 1 m. Infoort 0 the product and at a height of 1 m. **Note** 1: Liquid (chilled water) that can be used are either clean water and a 30 to 40% ethylene glycol solution. Note that there will be a drop in cooling capacity of 10% if using a 30 to 40% ethylene glycol solution. Alternatively, if deionized water is to be used, it should have an electrical conductivity of at least 1 µS(m.) **Note** 3: Loguid uptit from the unit in kW) is approx. 13 times that of the cooling capacity. **Note** 4: Depending on the operating environment, condensation may form on piping inside the product, and temporary leakage of water from the pump mechanical seals may also occur, therefore a drain pan should be installed if required.



0

5 10 15 20 25 30

Water Temperature (°C)

35 40

Discharge Pump Characteristic Curves

RKS401/402/602/752/753J-MV



35 40

• Room Temp.: 25 °C

· Chilled Liquid: Water

• Discharge Pump Circulating Load: Max.



1.0

0

5 10 15

20 25 30

Water Temperature (°C)

35 40



RKS401J-MV only Includes power cord with plug (3 m)

*Piping connection dimensions noted in drawings have a maximum tolerance of ±5 mm.

Mid-Grade Model • Water Cooled Type, Compact and Low Price WITH High-Precision Temperature Control (±0.1 °C)

RKS-GM Series

Water Cooled

The ORION RKS Series Mid-Grade water cooled chillers have already been adopted in many industries. An evolution of extensive functionality in an easy-to-use design.



RKS750G-MVW

RKS1500G-MVW



Solid

Sheet Metal Construction of External Surfaces Sheet metal constructed exterior that can withstand the long life of this chiller.

A sturdy construction that gets its rigidity from its frame design.

High Capacity Water Tank

The 10 L high-capacity water tank is designed to deal with liquid temperature fluctuations better.

Operation and Monitoring Via PC Possible



Specifications Chart

	opeomoatio		an					
	Model			RKS750G	RKS1500	G-MVW		
_	Cooling Capacity (50/60 Hz)	*1	kW	2.2 / 2.5		4.9 / 5.3		
Perfor	Heating Capacity (50/60 Hz) *5 k		kW	0.6 / 0).7	1.2/	1.4	
rmance Specific:	Operable ambient temperature range		°C		5 -	- 40		
	Operable Temp. Range (Lic	quid Temp.)	°C		5 -	- 35		
	Operating Water Press	ure	MPa	0.05 - 0.2 / 0.3	(50 / 60Hz)	0.1 -	0.5	
ations	Control Precision*4		°C		±C).1		
	Min. Operating Circulation Rate ((50/60 Hz)	L/min	10 (Head20	0 / 30m)	12 / 21 (He	ad: 50m)	
Po	Power Source ^{*2}		V(Hz)	Three-phase 200±10 % (50 / 60)	Three-phase 220±10 % (60)	Three-phase 200±10 % (50 / 60)	Three-phase 220±10 % (60)	
wer S	Power Consumption (50/60 H	łz) *1	kW	0.9 / 1.1	1.1	1.8 / 2.2	2.2	
pecifi	Electric Current*1		A	3.9 / 3.7	3.7	6.7 / 7.2	7.2	
icatio	Power Capacity *3 k\		kVA	2.0		3.9		
ß	Breaker Capacity		A	10		15		
Ope	eration Control Method			Electronic expansion valve capacity control				
	Compressor		on		Fully sealed	d rotary type		
		Output	kW	0.85		1.8		
Equ	Condenser			Plate type heat exchanger				
ipm	Heat exchanger	Constructio	on	Plate type heat exchanger				
Pht		Material		SUS316 (Brazing: Cu)				
Deta	Discharge pump	Constructio	on		Casca	ie type		
S		Output	kW	0.25	5	0.4		
	Water tank capacity		L		appro	ox.10		
	Refrigerant		1.		R4	10A		
Cha	rged Amount	140	kg	0.46		0.59		
Exte	ernai Dimensions (H × D ×	vv)	mm	615 × 500	× 3/3	933 × 590	J × 3/0	
Pro	Duct Mass (Dry weight)	I=\ *6	кg	55	2	85	°5	
Operating Noise Level (50/60 Hz) % dB 59 / 62 64 / 65					00			

*1 Operating conditions: Chilled water temp: : 20 °C. Cooling outpater temp: : 20 °C. Cooling capacity is at least 9% of listed figures. '2 Source voltage phase unbalance should be less than ±3 %. '3 The figure noted is when operating at the highest capacity in the normal operating range. '4 When the current load is continuously within ±10 %, and the ambient temperature is stable. However does not include starting times. '5 Maximum heating power when: Chilled water temperature: 20 °C, Ambient temperature: 20 °C, Socharge pump and head at maximum. Power will change depending on operating onotitions. '6 Operating noise levels are from a position of 1 m in front of the product and at a height of 1 m. Note :: Liquid (chilled water) that can be used are either clean water and a 30 to 40% ethylene glycol solution. Note that there will be a drop in cooling capacity of 10% if using a 30 to 40% ethylene glycol solution. Alternatively, if deionized water is to be used, it should have an electrical conductivity of at least 1 µS/cm. **Note 2**: Do not use aluminum parts for parts that will be wetted with the chilled water. Electrolytic corrosion of aluminum can cause clogging in the least exchanger. **Note 3**: Heat output from the unit (n kW) is approx. 13 times that of the cooling capacity.

RKS750G-MVW

50Hz

//////

Circulating Load (L/min)

Min. Working Circulation Rate

60Hz

Re

ead Los

XIIIII.

orking Lov

40

30

Head (m)

10

5

0

0 10 20 30

Cooling Capacity



Pump Characteristic Curves

RKS1500G-MVW 60 Min. Working Circulation Rat 50 11111111111 40 Head (m) 30 50F 20 Low Limi 10 Refrigeration Limit 0 40 0 10 20 30 40 50 60 Circulating Load (L/min)





When choosing a cooling tower, use the chart to the right as a reference guide and consult with y dealer or other qualified person regarding the specific choice.

ur `		Typical Cooling Water Flow Rate (m ³ /h)	Cooling Tower Capacity (kW)	Cooling Water Circuit Head Loss
. en	RKS750G-MVW	0.6	at least 4.5	10 m
	RKS1500G-MVW	1.5	at least 11.1	10 m





Includes Power Cord (Length outside the product: 3 m) 2 mm² x 4-conductors

Piping connection dimensions in the illustration have a maximum tolerance of ± 5 mm.

Economy Model **S-J Series**

New Model Compact Chiller No. 1 Performer in a Compact Body



Specifications Chart: Standard Models

					RKS-J	Series	
		viodei			753J-V	1503J-V	
	Cooling Capacity (5	60/60 Hz)	*1	kW	2.2 / 2.5	4.9 / 5.3	
Perfc	Heating Capacity (5	i0/60 Hz)	*1	kW	—	—	
orma	Ambient Temp. Range			°C	10 -	- 40	
nce	Operating Temp. Rang	ge (Liquid Temp.)		°C	15 -	- 35	
Specific	Operating Water Pr	essure		MPa	0.05 – 0.2 / 0.3 (50/60 Hz)	0.1 – 0.5	
atior	Control Precision		*4	°C	±2	.0	
S	Min. Operating Circulation	n Rate (50/60 Hz)		L/min	10 (Head: 20 / 30 m)	12 / 21 (Head: 50 m)	
Power	Power Source *2			V(Hz)	Three- 200 (5 220 (60	phase 50/60))) ±10%	
Spe	Power Consumption (50/60 Hz)	*1	kW	0.9 / 1.1, 1.1	1.8 / 2.2, 2.2	
cific	Electric Current (50	/60 Hz)	*1	Α	4.1 / 4.1, 4.1	6.8 / 7.4, 7.4	
ation	Power Capacity		*3	kVA	2.0	4.2	
SI	Breaker Capacity		*5	Α	10	15	
Ope	ration Control Metho	d			Compressor ON/OFF Control		
	Compressor			K/M	Fully Sealed	Rotary Type	
	Compressor			RVV.	0.85	1.8	
т	Condenser				Corrugated Fin and Tube Parallel Flow		
quip	Evaporator	Construction			Plate Type Heat Exchanger		
ome		Material			SUS 316 (Brazing: Cu)		
nt D	Discharge Pump	Construction			Cascade Type		
etai	Discharge i unip	Output		kW	0.25	0.4	
S	Water Tank Capacit	ty		L	Appro	ox. 17	
Refrigerant				R4 ²	10A		
Cha	rged Amount			kg	0.35	0.55	
Exte	ernal Dimensions (H	× D × W)		mm	615 × 500 × 375	933 × 590 × 375	
Proc	duct Mass (Dry weig	ht)		kg	45	67	
Exp	ort Standard CE and	UL (60 Hz only)		_		
Ope	rating Noise Level (50/60 Hz)	*6	dB	61 / 63	63 / 66	

¹¹ Under the following conditions: Chilled water temp.: 20 °C, Ambient temp.: 25 °C, Max, discharge pump circulating load. Cooling capacity is at least 95 % of listed figures. Heating capacity will change according to operating conditions. ¹² Source voltage phase unbalance should be less than 35 %. ¹³ The figure noted is when the equipment is operating at the highest capacity of its normal operating range. ¹⁴ When the current load is continuously within ±10 %, and the ambient temperature is stable. However does not include starting times or when the heat-load exceeds the chiler capacity. ¹⁵ Comes standard with a built-in overload protection circuit breaker (NFB). ¹⁶ Operating noise levels are from a position of 1 m in front of the product and at a built-in 4 met.

⁵ Comes standard wina builten overneed processon when whene (in c), o concerning the processon and the instant of it. Note 1: Liquid (chilled water) that can be used are either clean water and a 30 to 40% ethylene glycol solution. Note that there will be a drop in cooling cap of 10% if using a 30 to 40% ethylene glycol solution. Alternatively, if decinced water is to be used, it should have an electrical conductivity of at teast 1 µS/c Note 3: Do not use aluminum parts for parts that will be wetted with the chiled water. Electrolytic corrosion of aluminum can cause clogging in the heat excha Note 4: Depending on the operating environment, condensation may form on piping inside the product, and temporary leakage of water from the pump mechanical seals may also occur, therefore a drain pan should be installed if required.

Cooling Capacity



Discharge Pump Characteristic Curves

Oprerating Temp. Range



20

15

10

5

0 ∟ 20

DI

ųiiß

θŪ

Plus

Drain pan Drain Plug R 1/4

37

28



Discharge Pump Characteristic Curves (For factory options)



Pump w/Copper-Less Spec. Wetted Parts For RKS753J-V

Min. Working

30

Breaker

Rc 1/2

50H

0.2

0.1

0.05

50

60Hz

Working Lower Limi

40

Circulating Load (L/min)

Pressure (MPa)

Pump w/Copper-Less Spec. Wetted Parts For RKS1503J-V



External Dimensions (Units: mm)

RKS753J-V

(652)

615







*Piping connection dimensions noted in drawings have a maximum tolerance of ±5 mm.

RKS-JM / J Series Manufacturer Options and Accessories (Sold Separately)



Many Functional Specifications Available to Match Your Application

Factory Option Designation Description

Model: **RKS401J-MV-00000**

① Model	(123	4 5 6	6 External Surface
40 Compressor Output Rating: 400 Class	Dower Source			0 Surface painted steel sheet
60 Compressor Output Rating: 600 Class	1 Single-Phase 100 V * 1			1 Stainless steel (SUS304)
70 Compressor Output Rating: 750 Class	2 Single-Phase 200~230 V * 2	③ Model		5 Circuit Breaker
150 Compressor Output Rating: 1500 Class	Three-Phase 200 V (50/60 Hz) * 3	M Middle Grade Model	④ Pump / Water Circuit	0 Standard (NFB)
	3 ·220 V (60 Hz)	Blank Economy Model	0 Standard	1 Earth leakage circuit breaker (ELB)
*1 400 class only *2 J-MV Series only *3 *5 Includes external bypass piping kit. The	 750 class and 1500 class only *4 RKS402 e optional (sold-separately) Bypass Kit A/B 	2 Copper-free wetted parts *5		

Accessories (Sold Separately) Choose the Model that Best Suits Your Application. Contact us for details.

Model	Name		Description
RK-BP001	Bypass Piping Kit A	1	Quick Tube 3/8" Connector
RK-BP002	Bypass Piping Kit B	1	Rc 1/2 Pipe
RK-JB001	Compression Fitting ^{*6}	1	Inlet/Outlet 1/2", Brass
RK-VB001	Valve A	1	Inlet/Outlet 1/2", Brass
RK-VB002	Valve B	1	Inlet/Outlet 1/2", SUS
RK-VB003	Valve C	1	Inlet/Outlet 1", Brass
RK-VB004	Valve D	1	Inlet/Outlet 1", SUS
RK-WS001	Automatic Water Supply Kit	1	Float Valve ^{*3}
RK-LV001	Relief Valve Kit*6	1	Initial Setting: 0.3 MPa (Control range: 0.3 - 0.5 MPa)
RK-FR001	Flow Gauge A ^{*1}	1	Connected Flow Impeller Type (1.5 – 20 L/min)
RK-FR002	Flow Gauge B ^{*1}	1	Connected Flow Impeller Type (3 – 60 L/min)
RK-HF001	Water Filter Housing	1	Filter element sold separately
RK-FE001	Filter Element (5 µm)	1	
RK-FE002	Filter Element (10 µm)	1	
RK-FE003	Filter Element (25 µm)	1	
RK-FE004	Filter Element (100 µm)	1	
RK-CA001	Power Cable ^{*6}	1	For RKS402J-MV (W) 3 m For RKS602J-MV 3 m For RKS752J-MV 3 m
RK-CA002	Power Cable ^{*6}	1	For RKS753J-V • MV 3 m For RKS1503J-V • MV 3 m
RK-CA003	Power Cable ^{*6}	1	For RKS1502J-MV 3 m
RK-TH001	Differential Temperature Control Thermistor ^{*1}	1	Cable: 5 m
RK-HI001	Water Startup Heater Kit*1*4	1	Single-Phase 200 V, Capacity: 0.5 kW / for RKS402
RK-HI002	Water Startup Heater Kit ^{*1*4}	1	Single-Phase 200 V, Capacity: 1 kW / for RKS602•RKS75□
RK-HI003	Water Startup Heater Kit ^{*1*4}	1	Single-Phase 200 V, Capacity: 2 kW / for RKS150
RK-EB001	Remote Communications Interface	1	Connect external RS422 and RS485 accessories (sold separately).
RK-DI001	Electrical Conductivity Control Kit A ^{*1}	1	Bracket, deionizer, solenoid valve, electrical conductivity meter (10 - 500 µS/cm)
RK-DI002	Electrical Conductivity Control Kit B ^{*1}	1	Bracket, deionizer, solenoid valve, electrical conductivity meter (1 - 20 µS/cm)
RK-DI003	Deionizer Kit	1	Deionizer, valve
RK-DI004	Electrical Conductivity Meter A ^{*1}	1	Electrical conductivity meter (10 - 500 µS/cm)
RK-DI005	Electrical Conductivity Meter B*1	1	Electrical conductivity meter (1 - 20 µS/cm)
RK-RF001	Earthquake Resistance Bracket	1	Painted
RK-DP001	Drain Pan Kit ^{*1}	1	Drain pan (SUS), float tap
RK-DP002	Drain Pan	1	Drain pan (SUS)
RK-TR001	Transformer Kit	1	Three-phase 380 - 400 V (for three-phase models)
RK-YS001	Y-Strainer Kit A ^{*6}	1	40 mesh 1/2" brass
RK-YS002	Y-Strainer Kit B	1	40 mesh 1/2" SUS
RK-EY001	Eye Bolt Kit	1	Incl. M8×4 rubber washers

Bypass Piping Kit *2



Chilled water flow and pressure controllers are indispensable

*Flow Gauge A(B)



Can be used to monitor the chilled water circuit flow ra

*Remote Communications Interface



- *1: Items marked with a *require installation of the RK-EB001 communications interface. The communications expansion board must be present when these accessories are to be used.
- *2: Model numbers ending with -2**00 indicate models that include bypass piping in the chiller. *3: The water tank cannot be directly connected.Please supply water using a
- prepared water supply tank or cistern *4: The Water Startup-Heater Heater Kit requires its own single-phase 200 V power
- supply.
- *5: While we do sell individual accessories (sold separately), please contact your dealer if you want to purchase individual parts used with accessories (sold separately). *6: Not RoHS compliant (Please consult your dealer for compliant models.)
- All photographs show accessory (sold separately) equipment installed. These items require that the user assemble (and attach) these products (All accessories (sold separately) include an installation instructions.)

Relief Valve Kit

Automatic Water Supply Kit *3

Ball tap installed inside the tank. Trouble

Removes foreign material from the chilled water circuit. Choice of element. (Sold

Earthquake Resistance

Mount your chiller to the floor to prevent it

Bracket

from tipping over

Water Filter Housing

saving water-supply kit.



Indispensable when you don't want the chilled water circuit pressure to be higher than necessary

*Water Startup Heater Kit



Separate standing startup heater. Can also be used for control purposes.





Prevents damage in case of incidental water leaks. The chiller is placed in the drain pan and secured in place

*Electrical Conductivity Control Kit A(B)



Allows for purity management of circulating water. (Photo: Seen attached to the bypass circuit.)

21



Industry Recommended Accessories (Sold Separately) that Meet Your Needs

• For the Laser Industry

[Additional Accessories (Sold Separately)]

Remote Communications Interface • Electrical Conductivity Control Kit • Flow Rate Meter • Relief Valve • Water Filter Housing



Flow rate and pressure control to meet specs. for an oscillator or optical system. Choose a filter to keep foreign substances off your laser head. Chilled water purity is also maintained.

• For Research • Development • Inspection Industries

[Additional Accessories (Sold Separately)]

Remote Communications Interface • Flow Rate Meter • Water Filter Housing • Bypass Piping Kit • Differential Temperature Cotrol Thermistor



Flow rate management to X-ray source, or LED-UV. Choose a filter to keep foreign substance out of the chilled water circuit. Workstage temperature control (cascade control) possible. • For Liquid Crystal • Semiconductor Industries

[Additional Accessories (Sold Separately)] Remote Communications Interface •

Electrical Conductivity Control Kit • Bypass Piping Kit • Drain Pan Kit



Management of chilled water. Be prepared for water leaks with a drain pan and float switch. A factory option copperless spec. unit suitable for use with an aluminum circuit.

For Machine Tooling

[Additional Accessories (Sold Separately)] Remote Communications Interface • Bypass Piping Kit • Differential Temperature Cotrol Thermistor



Condensation prevention that tunes the chilled water temperature in conjunction with the external temperature (differential temperature control). Pressure and flow rate tuning via bypass control.

RKE and RKS Series Manufacturer Accessories (Sold Separately)

RKE and RKS Series Common with All Models

Ion Exchange Resin Purifying Equipment

Cartridge type and filter type for easy connections. It's easy to supply deionized water.

For circulating water setups.

Can prevent rises in electrical conductivity in the circulating water when installed in a bypass circuit within the chilled water circulation circuit.



Model		Deionizer "F" Assembly	Deionizer "F" Deionizer "G" Deionizer "H" Assembly Deionizer "H" Assembly		Deionizer Kit RK-DI003			
Part Number		04101157010	04103028010	04106210010	04106210020	04106501010	04106501010	
Applicable Models		RKE750A2-V RKE1500B2-V RKE1500B1-VW	RKE2200B-V RKE2200B-VW	RKS750G-MVW	RKS1500G-MVW	RKS401J-MV RKS402J-MV RKS602J-MV RKS602J-MV RKS752J-MV RKS753J-MV RKS753J-V	RKS1502J-MV RKS1503J-MV RKS1503J-V	
Ion Exchange Resin		RDI-55		DI-0-10BB		RDI-55		
Ion exchange resin part number		0A001386000		0A001108000		0A001386000		
Purification Capacity	L	Appro	ox. 55	Approx. 600		Approx. 55		
Water Quality	µs/cm			10 or	10 or lower			
Working Water Pressure	MPa			0.05	- 0.2			
Working Water Temperature	°C			5 -	- 40			
Dimensions		ø74.5-H122mm (Ion Exchange Resin)		ø185-364mm		ø74.5-H122mm (Ion Exchange Resin)		
Mass	g	Approx. 270 (Ion	Exchange Resin)	Approx. 5700		Approx. 270 (lon	Exchange Resin)	
Type of Installation Under the upper cabinet panel		Rear of Product		Rear of	Product			
Inlet/Outlet Piping Fixtures				-	_			
						Deionizer, Deionizer	Kit Installation Guide,	

Included Parts	Preliminary Deionizer *3, Upper Cabinet Panel, Ball Valve	Deionizer, Caster Mounting Bracket, Deionizer Inlet/Outlet Piping x 2 pcs, Special DI Hardware, Ion Exchange Resin, Hex Socket Head Bolt x 2 pcs, Chilled Water Inlet/Outlet Piping x 2 pcs, Two types of Nylon Tube x 1 each, Insert-Ring x 4 pcs	Barrel Nipple 1/4", Barrel Nipple 1/2" ×2 pcs, Unequal Tee Joint 1/2"×1/4"×2 pcs, Ball Valve 1/4", One-Touch Fitting - Straight 1/4" (Tube Diameter4mm), One-Touch Elbow Coupling 1/4" (Tube Diameter4mm)×3 pcs, Clear Polyurethane Tube 4mm850mm ×2 pcs, Insert-Ring x 4 pcs, Nylon Cable Tie ×2 pcs, Specifications Label
----------------	--	--	---

*1 Purification capacity figure based on water source standard purity level of 150 µS/cm. Capacity may vary according to water quality.

*2 The purification capacity does not indicate the volume of water at the intake during circulation. Ion exchange resin lifespan and water quality will change depending on the material of wetted parts and wetted surfaces, as well as the installation environment, etc.

*3 It is recommended that the initially supplied water be either water that has been purified by having passed through an ion exchange resin, or be commercially purchased deionized water or the like. If tap water (or a similar grade of water) is used, the effective life of the ion exchange resin will be greatly reduced. In such cases, please replace the ion exchange resin soon.

Caution) Avoid installing the ion exchange resin where it will be in direct sunlight or in places where there is a risk of it being damaged.

RKE and RKS Series ntroducing the ORION IoT System



"Communication Board" is required as an accessory (sold separately).

*2 :"Expansion Communication Board" is required as an accessory (sold separately) for RKS-J (M) series.



https://www.orionkikai.co.jp/download/iot/

Download Completed.

Note that our software is only offered in Japanese. Operation with non-Japanese operating systems has not been confirmed. Please refer to the instruction manual for required equipment and specifications.

RKE Series Important Unloading and Placement Information

Suspension Eyebolt

Min. 60



CAUTION =

Failure to follow instructions contained in a WARNING may result in death or serious injury.

Failure to follow instructions contained in a CAUTION may result in injury to the operator or damage to property.

Pre-Unloading and Unloading Procedures

Before Unloading

After unpacking, check the nameplate of the unit to ensure it is the correct model ordered. Abnormalities or other damage may occur during shipping or handling of the product. When receiving the product, check to make sure that there are no scratches or other abnormalities. If any damage or abnormality is detected, please contact the dealer where the product was purchased.

* For RKE2200B1-V/VW, check that the below mentioned included parts are present.

	Included Parts	Model		
Part Name Specifications		Qty per Unit	RKE2200B1-V	RKE2200B1-VW
Y-strainer	40 mesh equiv.	1 pc	0	0
Barrel Nipple	1B(For the Y-strainer)	1 pc	0	-
Short Pipe	1B Length100 mm(For the Y-strainer)	1 pc	-	0

WARNING

When using the accessory (sold separately) suspension eyebolts (RKE750A2-V, RKE1500B2-V, RKE1500B1-VW), always use all 4 eyebolts and make sure there is at least a 60° angle between the top face of the product and each of the suspension cables. Improper suspension may lead to the product tipping over or falling, which could result in injury.

Product Placement

Choice of Installation Location

Choose an installation location that is free from combustible materials, areas that could lead to electric shock, or environments that could damage the product.

CAUTION

Install on a level surface that can adequately support the weight of the product and bolt it down with anchor bolts or other means in order to prevent it from moving around. Lock all casters on models that are equipped with casters. Failure to install as indicated can result in water leaks or injury etc., from the product tipping over or falling.

- Ensure there is adequate space for heat ventilation as well as sufficient space for maintenance and inspection. If air cooled models are installed in an enclosed space as shown below, exhaust from the product can reenter at the heat exchange air intake port which will cause the refrigerant high-pressure to increase and could cause the product to shut down.
- If installing where a wind of 8 m/s or higher will be blown on it, measures to block the wind from hitting the product such as installation of a wind-break wall are required. (Air cooled models only.)

Unloading Procedure

The unit is heavy; please be careful when transporting it. When lifting the unit by forklift or handlift, make sure the forklift/handlift tines go underneath the wooden base of the package all the way and protrude from the other side.

* There are forklift slots on the base for RKE2200B1-V, VW.

Model	Mass (Water tank empt
RKE750A2-V-G1 (without casters)	68 kg
RKE750A2-V-G2 (with casters)	73 kg
RKE1500B2-V-G1 (without casters)	96 kg
RKE1500B2-V-G2 (with casters)	100 kg
RKE1500B1-VW-G1 (without casters)	95 kg
RKE1500B1-VW-G2 (with casters)	98 kg
RKE2200B1-V, VW-G1 (without casters)	135 kg
RKE2200B1-V, VW-G2 (with casters)	140 kg



\land WARNING

Installation of this product should be performed by your dealer or other qualified personnel. Improper installation by the end user may lead to water leakage, electric shock, fire or other problems.

3. Install out of direct sunlight and do not install where the product would be affected by heat. Exposure to direct sunlight or heat can cause the product to perform below the specified performance equal to the amount of the heat exposure. It can also lead to the activation of built-in protection devices which will prevent operation.



4. See the chart below for operable ambient temperatures. Operating outside the operable ambient temperature range can result in compressor breakdown, reduced cooling capacity, and can cause the product to stop operating due to activation of built-in safety devices.

Ambient Temp.	Model
-5 – 43 °C	RKE750A2-V, RKE1500B2-V, RKE2200B1-V
2 – 43 °C	RKE1500B1-VW, RKE2200B1-VW

5. If ducting is to be installed, have the installation performed by a gualified professional.

Ean Air Flow (m3/min)		Model	
	RKE750A2-V	RKE1500B2-V	RKE2200B1-V
50/00HZ	26	37 / 41	50 / 60

- 6. Install in a place that is generally free of dust and dirt. Installation in places with heavy dust and dirt can result in reduction in performance.
- 7. Condensation on internal piping or leakage from the water pump may occur depending on the operating environment.

\land WARNING

Installation of this product should be performed by your dealer or other qualified personnel. Improper installation by the end user may lead to water leakage, electric shock, and fire.

Water Supply and Drainage Construction

- •Reliably install water supply and drainage piping. Improper water supply and drainage construction could result in water spraying out, causing water damage to the surrounding area.
- •Ensure that the water supply pressure is 0.50 MPa or lower. Too high a pressure can damage the product and may lead to water leaks, flooding of the surrounding area, and electric shock.
- •Keep the cooling water pressure below 0.69 MPa. Higher pressure may damage the components to cause water leakage and mey result in electric shock.
- •When performing water piping, be careful to avoid the following points. Failure to do so can result in water leakage.

- 1. Overtightening the piping connected to the water supply port.
- 2. Having external forces on the water supply port.
- 3. Piping installation that does not absorb vibrations of water hammer, etc.
- •When connecting piping to the water supply port, always use two tools, using one to support the ball tap valve. *The ball tap valve is optional equipment.
- •Do not block the overflow piping. Blocked piping can cause water leakage inside the chiller.
- •Condensation on internal piping or leakage from the water pump may occur depending on the operating environment. Install a drain pan as needed.

Chilled Water / Cooling Water Piping

Piping Sizes

Piping diameters for each model are listed below.

Model Piping Item		RKE750A2-V	RKE1500B2-V	RKE1500B1-VW	RKE2200B1-V	RKE2200B1-VW			
Chilled Water Inlet	Piping Size	Rc1/2	Rc1						
	Tightening Torque	29.4		39.2 N • m or less					
Chilled Water Outlet	Piping Size	Rc1/2		Ro	:1				
Chilled Water Outlet	Tightening Torque	29.4		39.2 N • I	n or less				
Water Tank Drain	Piping Size			Rp 1/2					
(Overflow)	Tightening Torque	29.4 N • m or less							
Drain Pan Drain	Piping Size	R 1/4							
Port	Tightening Torque	19.6N • r	n or less	20.0 N • m or less	19.6 N • m or less				
Water Supply Port	Piping Size	Rc 1/2							
water Supply Port	Tightening Torque	39.2 N • m or less							
Cooling Water	Piping Size	-	_	Rc 3/4	-	Rc 3/4			
Piping Inlet	Tightening Torque	-	-	39.2 N • m or less	-	39.2 N • m or less			
Cooling Water	Piping Size	-	-	Rc 3/4	-	Rc3 /4			
Piping Outlet	Tightening Torque	-	_	39. 2N • m or less	-	39.2 N • m or less			
Cooling Water Drain	Piping Size	-	_	Rc 1/4	-	Rc 1/4			
Port	Tightening Torque	_	_	20.0 N • m or less	-	19.6 N • m or less			

Piping Methods

Piping installation should follow the guidelines printed below.

- 1. Check the chilled water inlet and outlet side ports.
- 2. Make pipe lengths as short as possible, and also avoid vertical and curved piping as much as possible.
- 3. When tightening piping connections, use 2 pipe wrenches or adjustable wrenches in order to grasp both sides of the joint.
- 4. If required, a (user provided) bypass valve or drain valve should be installed on the cooling water inlet port in order to ensure the minimum circulating water flow rate.

5. For RKE2200B1-V/VW. install

chilled water intake side port.

applied directly to the product's



the included Y-strainer on the Model RKE750A2-V, RKE1500B2-V RKE1500B1-VW sho



*Model RKE2200B1-V. VW shown.

connection ports. Failure to properly support piping can lead to equipment damage.

- 7. Always insulate piping. (Allow enough space between insulated pipes so that the lower right cabinet panel can be removed, and to allow operation of the bypass valve. Also make sure that the water pressure gauge will be visible after installation.)
- 8. Install the optional Float Valve Assembly if an automatic water supply

Electrical Wiring

Correct Wiring Installation

When performing electrical wiring, be sure to carefully follow the guidelines listed below.

- 1. Chose a power cable based on the breaker capacity shown in the table on the page 21. Always properly hook up the ground wire to the earth (ground).
- 2. Wire the product independently with its own overload protection multipurpose earth leakage breaker.
- *There is a combined use overload protection and earth leakage breaker installed for RKE2200B1-V, VW only.
- 3. Route the power cord through the power cord access hole, located on the lower-right part of the unit, to the inside of the terminal box. (Use 1 of the 2 available power cord access holes. The other can be used for remote control panel connections, etc.)
- 4. Always properly ground this unit. Connect the ground wire to a proper earth/ground point that has been installed by a qualified electrician.
- 5. Ensure the source voltage is within ±10 % of the specified voltage. Also make sure the source voltage phase unbalance * is within ±3 %.

system is to be constructed. Keep water supply pressure at or below 0.50 MPa.

- 9. Install reliable overflow piping in order to avoid water splatter.
- 10. Water supply piping should be installed with a cistern, not directly connected to the water supply.
- * Do not install piping higher than the overflow port.

Cooling Water Piping (Water cooled model)

- 1. Confirm the positions of the cooling water inlet and outlet ports. Confirm the position of the cooling water inlet and outlet ports by checking warning label on the product.
- 2. Follow the instructions below for piping work.
- (1) Mount the Cooling Water inlet valve ① and the Cooling Water outlet valve 2.
- (2) Be sure to mount the safety relief valve 3. The regulating valve that is installed in the cooling water circuit performs the opening

and closing of the valve automatically by detecting the refrigerant pressure. Thus, there is a possibility that the regulating valve becomes full-closed during operation. Be sure to install the safety relief valve for the water leakage prevention in the cooling water circuit, and



set the cooling water inlet pressure 0.69 MPa or lower.

- (3) Install the purge/drain valve 4.
- (4) Be sure to install the union coupling (5). Make sure that it can easily disassemble the product and cooling water piping when carrying out the cleaning of water-cooled condenser in inside the product.
- (5) Install a Y-strainer before the cooling water intake port.



^{*}Model RKE2200B1-V shown

*Phase unbalance (%) = (Maximum voltage [V] - Minimum voltage [V]) ÷ Average voltage of 3 phases (V) × 67. (Based on IEC61800-3.)

The current setting of the discharge pump overcurrent relay (THR) needs to be changed depending on the operating conditions. (RKE1500B2-V, RKE1500B1-VW)

	Discharge Pump	Discharge Pump Pressure Value										
Frequency	Less than 0.39MPa	0.39 – 0.5MPa										
50Hz	2.3 A (Default value)	2.3 A (Default value)										
60Hz	2.3 A (Default value)	2.6 A (Changed value)										

*When operating in areas with 60 Hz power, with a discharge pump pressure of 0.39 MPa or higher, the overcurrent relay (THR) current setting should be changed from 2.3 A to 2.6 A.

[IMPORTANT]

- Make sure the power cord does not come into contact with the motor or refrigerant piping within the product. Contact with hot surfaces could cause the cord to melt, resulting in an electrical short. (Secure power source wiring inside the distribution panel with cable ties.)
- Never allow the product to run dry. Always fill the water tank and confirm the water level before operating.
- Do not perform withstand voltage tests nor insulation resistance tests on this product. Doing so can damage the semiconductors used in the chiller control board or inverter. If the tests are deemed necessary, please consult your dealer.

RKE750A2-V

10

(Heater installed 15)

30 (High-speed model)

RKE1500B2-V

RKE1500B1-

vw

15

(Heater installed 20)

RKE2200B1-V

RKE2200B1-

vw

30

(Built-in)

30 (Built-in)

	Mode	ł	RKE750A2-V	RKE1500B2-V RKE1500B1-VW	RKE2200B1-V	RKE2200B1-VW			
Po	60								
Max	Maximum Operating Current (A)		6 (Heater installed 11)	11 (Heater installed 16)	19	16			
Те	Screw	Power Source	M3.5	M4					
m	Size	Ground		M4 Tapping (w/toothed lock washer)					
ina		Signal		M3.5					
Blog	Terminal Block	Power Source	7.5		10				
×	Width (mm)	Signal		7					

If Employing Remote Control Operation

Information Regarding Remote Operation and Communications Functions

Perform the wiring after first confirming the required specifications. *Please prepare terminals that fit M3.5 size screws.

1. Please confirm the unit specifications which are as follows.

	No-voltage contacts input (Alternating switch)					
Domoto	Maximum cable length: 20 m					
Operation Input Specifications	Input power resistance 1200 Ω					
	Open circuit voltage (Voc) 12 VDC					
	Short circuit current (Isc) 10 mADC					
	No-voltage relay contact output (c contact)					
Signal Output	250 VAC / 30VDC 5 A (Resistive load) (Normal Open)					
Specifications	250 VAC / 30VDC 3 A (Resistive load) (Normal Close)					
	Minimum operating current (For reference only) 5 VDC 10 mA					

2. Remote operation and signal output terminals are as follows:

	RKE750A2-V, RKE1500B2-V, RKE1500B1-VW, RKE2200B1-V, VW										
Remote Operation Contacts	Remote Operation	17 18									
Signal Output	Operation Signal	Close at operation									
Contacts	Alarm Signal	15 16 Close at alarm									

•When Using Communications Function

- 1. RS-232C
- (1) Connector: D-sub 9 pin female connectorr
- (2) Maximum data cable length: 15 m*
- *May differ depending on specific operating conditions.
- 2. RS-422A(RS-485)
- (1) Connector: Terminal block

Model

Breaker Capacity

(A)

Sensitivity (mA)

(2) Cable Gauge: AWG16 - 24

(Use AWG18 - 24 if 2 wires are to be inserted into a single terminal onnection.)

- (3) Length of Insulation to Remove From Cable: 10 mm
- (4) Attaching the Cables: Use either of the following methods: Attach the stripped wires as is. When performing hookups, be careful not to allow frayed wires to come into contact with or short out nearby wiring.
- (5) Maximum Cable Length: 100 m or less - May differ depending on operating conditions.

"Communication Board Assembly (P/N 04101126010)" is required.

*If connecting via RS-422A/485, make the connection by purchasing and using an RS-232C/422A converter.

(6) Connection Example



Ducting Design Points (Air cooled only)

• Ducting Design Points (For User-Installed Ducting)

If the installation area is narrow or has a low ceiling, the ambient temperature could raise to above 45 °C from heat coming from the ventilation outlet on the product. In such cases, ducting should be used to move the heat outside of the room or at least away from the product so that the effects of it do not cause the temperature near the product to rise. Take the following into consideration when planning duct work.

1. Duct Cross Sectional Area

(1) For ducting that rises up:

Model	RKE2200B1-V
Minimum Cross Sectional Area (m ²) [B×W]	0.21
Maximum Length (m)	20

(2) Rectangular ducting with bends:

•The cross sectional area should be greater than what is noted above, and the length of Lx and Ly should be less than 2 m. (See Fig. 1)

olf the length of Lx and Ly go over 2 m, then there should be a 20 cm

[IMPORTANT]

If ducting is to be affixed to the unit, first remove the suspension eyebolts from the top and replace them with M size bolts of the appropriate size. Ensure that there is no obstruction in the direction of the exhaust air flow within 2 m of the product. Failure to follow this rule will result in decreased air flow and insufficient heat ventilation, which can cause built-in safety devices to activate and stop operation of the product.



Points to Follow to Achieve Performance Specifications

•Important Points to Ensure Optimum Product Performance

- 1. Note the operating ranges and always operate the product within these ranges. Operating outside the designated ranges can damage the product.
- 2. Do not use aluminum parts for parts that will be wetted with the chilled water or cooling water. The chilled water and cooling water circuits operate with parts made of copper or copper alloys, so if user-installed wetted parts containing aluminum are present, the resulting copper ions will lead to electrolytic corrosion and copper deposits, which can cause water leakage around mechanical seals and clogging in the heat exchanger.
- Please consult your dealer before using any corrosion inhibiting water additives. Troubles such as the water becoming dirty, or damage to the refrigeration unit from clogging etc. can result depending on the type of additive used.
- 4. Operating with antifreeze rust inhibitor additives can reduce the lifespan of the mechanical seals.

[IMPORTANT]

Do not operate with the discharge pump water circuit (chilled water inlet and outlet ports) blocked. Operating with the circuit blocked can result in freezing or damage to the condenser, breakdown of the discharge pump, or disconnection of hoses.

gap between the hot exhaust air outlet from the unit and a fan should be installed on the duct outlet.

Do not allow Lx and Ly to be longer than 5m. (See Fig. 2.)

*The duct in the figure is one example. The particular direction the duct exhaust port goes from the unit does not matter, however the following important points must be enforced.



• Take the following into consideration when planning duct work.

Fan	Recommended Fan	Minimum Required Air Flow (m³/min)				
Model		Power Source 50Hz	Power Source 60Hz			
RKE750A2-V	Consult a qualified professional for installation.	26				
RKE1500B2-V	Consult a qualified professional for installation.	37	41			
RKE2200B1-V	EF-35DTB3-(Q) (MITSUBISHI)	50	60			

- When using anti-freeze brine solution, a 30 to 40% solution of industrial use ethylene glycol is recommended. However, if operating under the following conditions, it is possible that it may go bad. Therefore, in such cases, depending on the water temperature, anti-freeze operation through automatic operation of the pump is recommended.
- If the water temperature does not go below 20 °C even when the product is stopped.
- (2) If the water in the water tank has not been replaced in over 3 months.
- Frequently switching the product ON and OFF can lead to breakdown. Allow at least 3 minutes between subsequent operations of the product.
- Always fill the water tank and check the water level before operating. If the liquid level gauge goes below the "E" mark, an alarm will be generated and the product cannot be operated.
- The water pressure at the water supply port should be 0.50MPa or less. Too high pressure will result in the water supply failing to shut off or leakage.
- Always keep the water clean, inspect the water circuits monthly, and replace the water when necessary. Dirty water can damage mechanical seals and lead to leakage.
- Clean the condenser filter every month.
- Water cooled: The cooling water should be checked monthly to ensure that it is clean. The water should be changed if dirty.

RKS-J/J-M/G-MVW Series Important Unloading and Placement Information

WARNING = Failure to follow instructions contained in a WARNING may result in death or serious injury.

CAUTION =

Failure to follow instructions contained in a CAUTION may result in injury to the operator or damage to property.

Pre-Unloading and Unloading Procedures

Before UnloadingAfter unpacking

Before UnloadingAfter unpacking, confirm that the model number on the nameplate matches the model number of the item ordered. Abnormalities or other damage may occur during shipping or handling of the product. When receiving the product, check to make sure that there are no scratches or other abnormalities. If any damage or abnormality is detected, please contact the dealer where the product was purchased.

WARNING

When using the accessory (sold separately) suspension eyebolts, always use all 4 eyebolts and make sure there is at least a 60 ° angle between the top face of the product and each of the suspension cables. Improper suspension may lead to the product tipping over or falling, which could result in injury.



Product Placement

Choice of Installation Location

Choose an installation location that is free from combustible materials, areas that could lead to electric shock, or environments that could damage the product.

CAUTION

Install on a level surface that can adequately support the weight of the product and fix the product down with anchor bolts or other means in order to prevent it from moving around. Failure to install as indicated can result in water leaks or injury etc., from the product tipping over or falling.

- Ensure there is adequate space for heat ventilation as well as sufficient space for maintenance and inspection. If air cooled models are installed in an enclosed space as shown below, exhaust from the product can reenter at the heat exchange air intake port which will cause the refrigerant high-pressure to increase and could cause the product to shut down.
- If installing where a wind of 8 m/s or higher will be blown on it, measures to block the wind from hitting the product such as installation of a wind-break wall are required. (Air cooled models only.)

Overhead Obstacles (Roof, eaves, ceiling, etc.)



3. Install out of direct sunlight and do not install where the product would be affected by heat. Exposure to direct sunlight or heat can cause the product to perform below specified performance equal to the amount of that exposure. It can also lead to the activation of built-in protection devices which will prevent operation.

Unloading Procedure

The product is heavy; please be careful when transporting it.

Model		Mass (Water tank empty) Model				Mass (Water tank em		
RKS401 • 402J-MV	-0 * *00	42 kg		RKS1502J-MV	-0 * *00	72 kg		
RKS402J-MV	-1 * *00	46 kg		RKS1502J-MV	-2 * *00	70 kg		
RKS401 • 402J-MV	-2 * *00	41 kg		RKS1503J-MV	-0 * *00	68 kg		
RKS602 • 752J-MV	-0 * *00	45 kg		RKS1503J-V	-0 * *00	67 kg		
RKS602 • 752J-MV	-1 * *00	49 kg		RKS1503J-MV	-2 * *00	66 kg		
RKS602 • 752J-MV	-2 * *00	44 kg		RKS1503J-V	-2 * *00	65 kg		
RKS753J-MV	-0 * *00	46 kg		RKS402J-MVW	-00000	44 kg		
RKS753J-V	-0 * *00	45 kg		RKS402J-MVW	-20000	43 kg		
RKS753J-MV	-1 * *00	50 kg		RKS750G-MVW		55 kg		
RKS753J-V	-1 * *00	49 kg		RKS1500G-MVW		85 kg		
RKS753J-MV	-2 * *00	45 kg						
RKS753J-V	-2 * *00	44 kg						

\land WARNING

Installation of this product should be performed by your dealer or other qualified personnel. Improper installation by the end user may lead to water leakage, electric shock, fire or other problems.

4. Please operate this product within the ambient temperature range as listed below:

		Model										
Ambient Temp. Range (°C)	RKS401 • 402 • 602 • 752 • 753 • 1502 • 1503J-MV • RKS402J- MVW	RKS753 • 1503J-V	RKS750 • 1500G-MVW									
	5 - 45	10 - 40	5 - 40									

- 5. Operating at temperatures below than 5 °C can damage the compressor. Operating at temperatures above 45 °C will result in reduced thermal performance of the condenser, reduced ability to cool the product, and could cause built-in safety devices to activate and product operation to stop.
- 6. If ducting is to be installed for air cooled models, have the installation performed by a qualified professional.

Fan Flow Rate	Model	
(m³/min)	RKS401 • 402 • 602 • 752 • 753J-(M)V	RKS1502 • 1503J-(M)V
50/60Hz	24 / 28	48 / 56

Install in a place that is generally free of dust and dirt. Installation in places with heavy dust and dirt can result in reduction in performance.

[Ambient Temperature]



Water Supply and Drainage Construction

•Reliably install water supply and drainage piping. Improper water supply and drainage construction could result in water spraying out, causing water damage to the surrounding area.

Chilled Water / Cooling Water Piping

Piping Sizes

Piping diameters for each model are listed below.

•Ensure that the water supply pressure is 0.50 MPa or lower. (When an accessory (sold separately) ball tap is installed.) Water leakage resulting from product damage can cause surrounding areas to become wet and may also cause electrical shocks.

	Model	RKS-JM Series	RKS-J Series	RKS-GM Series (Water Cooled)					
Piping Item		401 • 402 • 602 • 752 • 753 • 1502 • 1503J-MV	402J-MVW	753 • 1503J-V	750G-MVW	1500G-MVW			
Chilled Water	Piping Size	Pc1/2 20 N • m or	loss						
Inlet	Tightening Torque								
Chilled Water	Piping Size								
Outlet	Tightening Torque								
Overflow Dert	Piping Size	Do 1/2 20N am or loco							
Overnow Fort	Tightening Torque	RC 1/2 J9N • III OF less		_	-				
Water Tank	Piping Size	One Touch Joint (Cap)							
Drain	Tightening Torque	_		Rp 1/2 29N • III OF less					
Cooling Water	Piping Size		Rc 1/2		Rc 1/2	Rc 3/4			
Piping Inlet	Tightening Torque	—	less	—	less	less			
Cooling Water	Piping Size		Rc 1/2		Rc 1/2	Rc 3/4			
Piping Outlet	Tightening Torque	-	less	_	less	less			

•Piping Methods

Piping installation should follow the guidelines printed below. 1. Check the cooling water inlet and outlet side ports.

- 2. Make pipe lengths as short as possible, and also avoid vertical and curved piping as much as possible.
- 3. When tightening piping connections, use 2 pipe wrenches or adjustable wrenches in order to grasp both sides of the joint.
- 4. If required, a (user provided) bypass valve or drain valve should be installed on the cooling water inlet port in order to ensure the minimum water circulation flow rate.
- 5. Make sure that there is not excessive weight or vibration on the product from the connected piping. Longer lengths of horizontal piping should be supported with additional support hardware to ensure unreasonable forces are not applied directly to the product's





connection ports. Failure to properly support piping can cause damage.

6. Piping should be insulated. (Allow for enough space between insulated pipes so that the lower right cabinet panel can be removed, and to allow operation of the bypass valve. Also make sure that the water pressure gauge will be visible after installation.)

- If connections to the chilled water inlet and outlet ports are reversed, then no cooling will occur.
- •When tightening piping, use 2 wrenches (pipe wrenches or adjustable wrenches, etc.) to support both sides of the connection and tighten to a torque according to the chart. (Fig. 1)
- •Be careful during piping installation not to allow dirt, foreign material, sealing materials, etc., to enter the water circuit or water tank.
- It is recommended that piping be installed in order to avoid leakage from overflow.
- •Always install valves (user supplied) at the cold water inlet and outlet ports.
- •The drain valve is used to drain water from the piping when the product is not to be used for extended periods of time.
- If there is a chance that the cold water circuit could be blocked while the product is operating, then a safety valve (relief valve) should be installed to prevent water leakage and to maintain operation within the discharge pump operating range.
- Install a Y-strainer (user supplied) on the product inlet port. Also install a drain pan as required.
- Install a drain pan, as condensation may form on piping inside the product depending on the operating environment.
- •Do not block the overflow piping. Blocked piping can result in water leakage within the product.
- •Keep the discharge pump pressure within the specified operating range. If the pressure exceeds the upper limit, it could lead to freezing or damage to the evaporator, pump damage, or hoses coming off. If pressure goes below the lower limit, it could result in damage to the pump mechanical seals.
- •Install the optional Bypass Valve Piping Kit (sold separately) if the pressure could exceed the prescribed upper limit, and operated the bypass valve to control the water pressure.

A Bypass Piping Kit is available as an optional accessory (sold separately) for RKS J,JM Series models.*

* Model numbers ending with -2**00 indicate models that include bypass piping in the chiller.



•Pipe Connection Procedure (Water cooled: RKS402J-MVW, RKS750 • 1500G-MVW)

- 1. Confirm the positions of the cooling water inlet and outlet ports. Install the cooling water inlet valve ① and cooling water outlet valve ②.
- 2. Be sure to mount the safety relief valve 3.
- The regulating valve that is installed in the cooling water circuit performs the opening and closing of the valve automatically by detecting the refrigerant pressure. Thus, there is a possibility that the

regulating valve becomes full-closed during operation. In order to prevent water leakage, maintain a water inlet pressure of 0.69 MPa or lower by installing a safety valve (relief valve) on the cooling water circuit.



- 3. Install the purge/drain valve ④. 4. Be sure to install the union
 - coupling 5. Make sure that it can easily disassemble the product and cooling water piping when carrying out the cleaning of water-cooled condenser in inside the product.
- If connections to the chilled water inlet and outlet ports are reversed, then no cooling will occur.
- •When tightening piping, use 2 wrenches (pipe wrenches or adjustable wrenches, etc.) to support both sides of the connection and tighten to a torgue according to the chart. (Fig. 1)
- Install the included Y-strainer before the cooling water inlet.

Electrical Work

- •Ensure that all electrical wiring is done in accordance with relevant electrical construction regulations as well as the directions outlined in this manual. Furthermore, the product must be powered on its own electrical circuit. Installation with an insufficient power supply or improper installation can result in electric shock or fire.
- •Be sure to connect the prescribed cables in a reliable manner, ensuring that there are no external forces exerted on cables or contact connectors. Improper cable connections may lead to electric shock, overheating of the contacts, or fire.
- •Do not modify this product. Improper modifications to wiring or piping within the product can lead to electric shock or fire. Furthermore, modifying the product will void the product warranty.
- •Never change the settings of built-in safety devices. Modifying such

settings can lead to an explosion or fire.

- •Always properly ground this product. Do not attach the grounding wire to gas pipes, water pipes, lightning rods, etc. Improper grounding can lead to electric shock. (Installation of a Class-D ground hookup must be performed by a qualified electrician.)
- •An earth leakage breaker must be installed. Failure to install an earth leakage breaker can lead to electric shock.
- •Connect the product to a commercial power source. (Connection to the secondary side of the inverter will damage the product.)
- •Ensure the source voltage is within ±10 % of the specified voltage. Also make sure the source voltage phase unbalance* is within ±3 %.

Ensure the source voltage is within ±10 % of the specified voltage. Also make sure the source voltage phase unbalance is within ±3 %.

*Phase unbalance (%) = (Maximum voltage [V] - Minimum voltage [V]) ÷ Average voltage of 3 phases (V) × 67. (Based on IEC61800-3.)







Electrical Wiring [RKS750, 1500G-MVW]



*RKS750 and 1500G-MVW models include a power cord.

RKS Series Important Unloading and Placement Information

If the power cord is to be extended, refer to the chart below which shows the maximum operating current when choosing the cord. Always properly connect a ground wire to the product. (RKS401J-MV has a power cord which includes the grounding wire and therefore it should be not extended.)

-									-	-									
Model		RKS-JM Series												RKS-J Series				RKS-GMVW Series	
	401J-MV	402	J-MV	602 • 7	52J-MV	753.	J-MV	1502	J-MV	1503	J-MV	402J-MVW (V	Vater cooled)	753	J-V	150	3J-V		
Model Suffix	-0 * * 00 -2 * * 00	-0 * * 00 -2 * * 00	-1 * * 00	-0 * * 00 -2 * * 00	-1 * * 00	-0 * * 00 -2 * * 00	-1 * * 00	-0 * * 00	-2 * * 00	-0 * * 00	-2 * * 00	-00000	-20000	-0 * * 00 -2 * * 00	-1 * * 00	-0 * * 00	-2 * * 00	750G-MVW	1500G-MVW
Power Source (V • Hz)	Single-phase100 V ±10 %	1	φ200 - 230:	±10 % • 50/6	50	3φ200±10 220±10	% • 50/60,) % • 60	1φ200 - 2 +10 %	230 -5 %, • 50/60	3φ200±10 220±10	% • 50/60,) % • 60	1φ200 - 2 50	30±10 % • /60	3φ200	3φ200±10% • 50/60, 220±10% • 60				% • 50/60,)% • 60
Maximum Operating Current (A)	_	7.5	12.0	10	15.5	6	11.5	21	21.5	12	12.5	6	.0	6.0	11.5	12	12.5	4.0	8.1

Wire the product independently with its own overload protection multi-purpose earth leakage breaker.

Model		RKS-JM Series												RKS-J Series				
	401J-MV 402J-MV			602 • 7	602 • 752J-MV 753J-MV		J-MV	1502J-MV	1503J-MV	402J-MVW (Water cooled)		753J-V		1503J-V				
Model Suffix	-0 * * 00 -2 * * 00	-0* * 0 -2* * 0	-1* * 00	-0 * * 00 -2 * * 00	-1 * * 00	-0 * * 00 -2 * * 00	-1 * * 00	-0 * * 00 -2 * * 00	-0 * * 00 -2 * * 00	-00000	-20000	-0 * * 00 -2 * * 00	-1 * * 00	-0 * * 00 -2 * * 00	750G-MVW	1500G-MVW		
Circuit Breaker (A)	15	10	15	15	20	10	15	30	15	1	0	10	15	15	10	15		

The current setting of the discharge pump overcurrent relay (THR) needs to be changed depending on the operating conditions. (RKS1503J-V and RKS1500G-MVW Only)

	Discharge Pump Pressure Value		
Frequency	Less than 0.39 MPa	0.39 - 0.5MPa	
50Hz	2.3 A (Default value)	2.3 A (Default value)	
60Hz	2.3 A (Default value)	2.6 A (Changed value)	

*When operating in areas with 60 Hz power, with a discharge pump pressure of 0.39 MPa or higher, the overcurrent relay (THR) current setting should be changed from 2.3 A to 2.6 A.

If Employing Remote Control Operation

If remote operation and signal outputs are to be utilized, please confirm wiring specifications before performing wiring construction. When wiring, remove the terminal block on the back plate and connect with AWG 16-24 cables.

Carefully check the following specifications.

Remote Operation Input Specifications	Contact Input Specifications (No-Volta Max. wiring length: Input power resistance Open circuit voltage (Voc) Short circuit current (Isc) Voltage Input Specifications Max. wiring length: Rated voltage	age) Max. 20 m 1k Ω 12 VDC 10 mADC Max. 20 m 12 VDC - 24 VDC
	Input power resistance	1k Ω
Signal Output Specifications	No-Voltage Contact Specifications AC250V 5A / DC30V Minimum operating current (For reference only	3 A(Resistive load)) 5 VDC 100 mA

[IMPORTANT]

- Make sure the power cord does not come into contact with the motor or refrigerant piping within the product. Contact with hot surfaces could cause the cord to melt, resulting in an electrical short. (Secure power source wiring inside the distribution panel with cable ties.)
- Never allow the product to run dry. Always fill the water tank and confirm the water level before operating.
- Do not perform withstand voltage tests nor insulation resistance tests on this product. Doing so can damage the semiconductors used in the chiller control board or inverter. If the tests are deemed necessary, please consult your dealer.



RKS J/ JM Series



•RKS750, 1500G-MVW

	Remote Operation Terminal Block	Remote Operation	
	Signal Output Contacts	Operation Signal	23/When Power is Cut Off : 24-26 Closed, 25-26 Open 25/When Equipment is Stopped : 24-26 Closed, 25-26 Open 26/When Equipment is Operating : 24-26 Open, 25-26 Closed
V		Alarm Signal	22/When Power is Cut Off : 27-29 Closed, 28-29 Open 29/Warning Disabled : 27-29 Closed, 28-29 Open (Default) 29/During Alarm Condition : 27-29 Open, 28-2 9Closed (Default)

•Perform remote operation and signal output wiring so that no undue strain is placed on connection terminal block.

When Using Communications Functions

Attach the stripped wires and use as is.
 Data cable wire size: AWG16 - 24
 Data cable max. length: Max. 100 m (from host to terminal end)
 *May differ depending on specific operating conditions.
 *RK-EB001: "Expansion Communication Board" is required for RKS-J/JM series.

RKE and RKS Series Common Data

Cooling Water

Choosing Cooling Water

Basically, cooling water for the water cooled condenser can be underground water, tap water, or water from a cooling tower. However, the final choice should be made after carefully considering the following points.

•Water Quality Standard Guidelines

Primary cooling water (refrigeration unit condenser cooling water, constant temperature water for the water temperature controller, and humidification water) should meet the water quality standard as described in the chart on the right.

- 1. Primary Cooling Water Quality Standards
- (1) If tap water is used as the primary cooling water for water cooled equipment, then the water should meet the following water quality standard.
- (2) Within the "Tendency toward" column, items marked with ao indicate this component can lead to corrosion or scaling as indicated.
- (3) The 15 items listed to the right are the primary components that can lead to corrosion or scaling.

•Using Tap Water

Note that the constant release of tap water (where the cooling water outlet circuit is in an open loop system) can result in dezincification corrosion and breakdown of the water regulating valve.

* Use for make-up water when operating with a cooling tower.

Clause		Cooling Water		Tendencies	
		Circulation water	Supplied water	Corrosion	Scaling
	pH (25 °C)	6.5 to 8.2	6.0 to 8.0	0	0
S	Electric conductivity (µS/cm) (25 °C)	800 or below	300 or below	0	0
itan	Chloride ion (mgCl ⁻ /L)	200 or below	50 or below	0	
Idar	Sulfate ion (mgSO ₄ ²⁻ /L)	200 or below	50 or below	0	
d It	Acid consumption (pH4.8) (mgCaC ₃ /L)	100 or below	50 or below		0
em	Total hardness (mgCaCO ₃ /L)	200 or below	70 or below		0
S	Calcium hardness (mgCaCO ₃ /L)	150 or below	50 or below		0
	Ionic Silica (mgSiO ₂ /L)	50 or below	30 or below		0
	Iron (mgFe/L)	1.0 or below	0.3 or below	0	0
Ref	Cu (mgCu/L)	0.3 or below	0.1 or below	0	
ere	Sulfide ion (mgS ²⁻ /L)	None detected	None detected	0	
nce	Ammonium ion (mgNH ₄ ⁺ /L)	1.0 or below	0.1 or below	0	
) Ite	Residual chlorine (mgCl/L)	0.3 or below	0.3 or below	0	
su	Free carbon dioxide (mgCO ₂ /L)	4.0 or below	4.0 or below	0	
	Stability index	6.0 to 7.0	-	0	0

^r Excerpt from JRA-GL-02-1994 guidelines from The Japan Refrigeration and Air Conditioning Industry Association.

Chilled Water

Chilled Water Standards

Liquid (chilled water) that can be used are either clean water and a 30 to 40 % ethylene glycol solution. Alternatively, if deionized water is to be used, it should have an electrical conductivity of at least 1 μ s/cm. Cooling

Item		Standard levels
s	pH(25 °C)	6.8 - 8.0
tan	Conductivity (µS/cm) (25 °C)	1 - 400
dar	Chloride ion (mgCl ⁻ /L)	Max. 50
dc	Sulphate (mgSO ₄ ⁻² /L)	Max. 50
om	Acid consumption (pH4.8) (mgCaCO ₃ /L)	Max. 50
pon	Total hardness (mgCaCO ₃ /L)	Max. 70
lents	Calcium hardness (mgCaCO ₃ /L)	Max. 50
	Silica ion (mgSiO ₂ /L)	Max. 30

non-approved liquids can result in equipment damage, leaking, and possible electric shock or electrical shorts.

	Item	Standard levels
	Iron (mgFe/L)	Max. 1.0
Reference components	Copper (mgCu/L)	Max. 1.0
	Sulfide ion (mgS ²⁻ /L)	Not detected
	Ammonium ion (mgNH $_4^+/L$)	Max. 1.0
	Residual chlorine (mgCl/L)	Max 0.3
	Free carbon dioxide (mgCO ₂ /L)	Max. 4.0

* Excerpt from JRA-GL-02-1994 guidelines from The Japan Refrigeration and Air Conditioning Industry Association.

Orion Products -- Service and Safety

Safety Notes

- Before operating this equipment, please read the operating manual carefully, and only use as indicated.
- For installation of this equipment and required wiring, employ a qualified person or consult with your dealer.
- Be sure to select equipment which suits your needs. Do not use this equipment for purposes other than those for which it is intended. Doing so can lead to accidents or equipment breakdown.

Air-Cooled Models

If the condenser becomes clogged with dust or dirt, heat exchange will be greatly reduced and electricity consumption will increase. This will lead not only to decreased performance, but can also lead to the activation of built-in safety devices, and eventual damage to the equipment. For these reasons, the condenser should be cleaned on a regular basis.

Regarding After-Service

- For information regarding repair of equipment that has been in operation, please consult your dealer.
- The customer will be responsible for charges incurred for repairs conducted after the warranty period has expired. In cases where equipment function can be improved by certain service procedures, such procedures will be taken at the specific request of the customer.
 Regarding spare parts... "Spare parts" are those which are
- Regarding spare parts... "Spare parts" are those which are necessary in order to maintain the function of the product. It is the policy of ORION to maintain a stock of replacement parts for 7 years after production of the product ceases.

Refrigerant Management

Some of the products in this catalog contain HFC refrigerants. Refrigeration technologies that use HFC refrigerants are essential for achieving efficient temperature control, and while such technologies make great contributions toward saving energy, there is also concern of the impact that the accidental release of HFC refrigerants into the atmosphere has on global warming.

When dealing with HFCs, please ensure compliance with laws and regulations and be sure to manage them appropriately for your safety and for the protection of the environment.

• Water-Cooled Models

In general, water used to cool condensers will be wellwater, tap water, or water from a cooling tower. However water of insufficient quality can lead to scaling in cooling pipes resulting in lower levels of heat exchange, increased electricity consumption and lower performance. Therefore water quality should be confirmed on a regular basis.

Recommended Maintenance Inspections

 Depending on the particular item, extended use can lead to the product becoming dirty or worn, which can lead to decreased performance. In order to realize continued best performance of this equipment, in addition to prescribed customer maintenance, it is also recommended that regular inspections be conducted. (Service and inspection fees apply.) For further information please consult your dealer or contact ORION directly.

•GWP Values of Refrigerants Used in Our Products

Pefrigerant	Global Warming Potential	
Reingerant	(100-year GWP)	
R134a	1430	
R404A	3920	
R407C	1770	
R410A	2090	
R32	675	

* For details about the refrigerant used in specific products, please refer to the product's specification page.

ORION is continuing to develop a complete and trustworthy nationwide network of expedient sales and service -- everywhere, anytime.



*ORION has wide reaching regional service bases in various countries throughout the world. Please consult your ORION dealer for details.

For inquiries, please contact the following representative:



at Main Plant, Koshoku Plant and Chitose Plant.





* Warranty period of the refrigerant circuitis 2 years from the date of purchase (or 10.000 hours of operating time)

ORION MACHINERY CO., LTD.

International Group Head Office 246, Kotaka, Suzaka-shi, Nagano-ken, 382-8502 Japan TEL +81-(0)26-246-5664 FAX +81-(0)26-246-5022 Email: kokusai@orionkikai.co.jp 246, Kotaka, Suzaka-shi, Naqano-ken, 382-8502 Japan

 Head Office
 246, Kotaka, Suzaka-shi, Nagano-ken, 382-8502.

 & Factory
 TEL +81-(0)26-245-1230 FAX +81-(0)26-245-5424 URL: http://www.orionkikai.co.jp

Actual product colors may vary slightly from the pictures.

 Please note that the structure or specifications of products contained in this catalog are subject to change without prior notice.